orp-chlorine monitoring

M&D offers a selection in monitoring for residual, total and gas-phase chlorine measurement, using ion-specific or ORP systems. www.murphyanddickey.com

Tips for Accurate ORP Monitoring

For over fifteen years, ORP measurement has been used successfully for free chlorine monitoring in wastewater treatment, cooling tower control, and water for disinfection. It is effective in high-maintenance areas where solids build up would cause fouling of membrane-type chlorine sensors. The relationship between ORP and chlorine at various pH levels has been well-documented.

Unlike membrane-style specific-ion chlorine sensors, differential ORP sensors are more robust, lower-cost and coating-resistant. ORP electrode surfaces can be cleaned with soap-and-water or mild acid solutions. They have replaceable junctions and may be used in-line or submerged in a tank. ORP gives a more general, "millivolt" reading, as opposed to "ppm chlorine", but the results are more reliable in very low chlorine levels.

Chlorine concentration is affected by pH changes. pH of the solution needs to be controlled prior to taking a chlorine measurement. The pH should be stable and not fluctuate by more than 0.1 to 0.2 pH units.

Ferric chloride is typically used as a coagulant. If this is added upstream of the chlorine addition, a clarification process should be used.

An online pH/ORP analyzer displays pH and ORP readings that can be easily cross-referenced against a customized chlorine-ORP chart.

Call or email M&D to review your requirements today. 630-655-1080



Murphy & Dickey, Inc. 930 N. York Road # 205 Hinsdale, IL 60521 630-655-1080 phone 630-655-1085 fax sales@murphyanddickey.com



Free Chlorine ORP/mV vs. pH



Be Careful, ORP Is Non-Specific!

Variables in the process stream must be eliminated to ensure accurate chlorine correlation. Stabilized pH is key when using ORP to control chlorine feed. Here's why: *An ORP sensor measures all oxidation and reduction reactions in solution.* The assumption in ORP-chlorine monitoring is that the addition of the chlorine is the most dominant reaction in the solution. By eliminating other variables in the process then this will hold true.

Customizing Your Chlorine System Data The pictured ORP vs. Chlorine charts are available can be used as a guide to develop a customized chart for your facility.

During the first month of measurement, a daily or twice-a- day reading of chorine level as measured by a hand-held colorimeter or by a laboratory titration. The value is then plotted verses ORP as displayed by the analyzer. This enables development of a custom curve like those pictured here. *More questions? Contact M&D: 630-655-1080. Additional tech notes can be found at www.murphyanddickey.com.*

Need Chlorine Pumps & Mixers?

In addition to providing instrumentation to major industrial facilities, refineries and municipal water treatment plants for over 70 years - thousands in Northern Illinois alone, Murphy & Dickey is a supplier of Chemical Feed Pumps & Mixers! www.murphyanddickey.com

