

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK

Sales Code:	Option:	R_D:	SCDesc:
A07500	0035	R	AFTER FRAME,75 IN.
OPG900	0001	R	PAINT - OWNER/OPERATOR, WINDSWEPT, COLOR COMBINATION 21, ACCENTED MON
TFA200	0030	R	TIRE SIZE-FRONT,11RX24.5-14,RADIAL,11,X24.5,-14
TRA200	0004	R	TIRE SIZE-REAR,11RX24.5-14,RADIAL,11,X24.5,-14
W22700	0014	R	WHEELBASE,227 IN.
10AE00	0074	R	AXLE, FRONT,12000 LB,FORD,-,STEEL,-
11FB00	0004	R	REAR AXLE,TANDEM,40000,ROCKWELL,RT-40-145,3.73,STD TRACK,STL
13AB00	0033	R	SHOCK ABSORBERS - FRONT,-,-
13AF00	0013	R	DRAG LINKS & TIE RODS,GREASEABLE
13AP00	0028	R	BRAKE DRUMS - FRONT,CENTRIFUSE,-
13AR00	0030	R	BRAKE DRUMS - REAR,CENTRIFUSE,-
13AT00	0015	R	HUBS - FRONT,ALUMINUM,-
13AV00	0029	R	HUBS - REAR,ALUMINUM,-
13AY00	0034	R	WHEEL SEALS FRONT,-,-
13A000	0034	R	WHEEL SEALS REAR,-,-
13A900	0010	R	DIFFERENTIAL,MAIN-NON LOCKING
13BT00	0039	R	STEERING,POWER
16AW00	0042	R	BRAKES-FRONT,AIR CAM,-,15" X 4",-
16A000	0060	R	BRAKES-REAR,AIR CAM,-,16.5" X 7",-
19AK00	0007	R	VALVE - BRK HAND CONT,-
19AL00	0031	R	MOISTURE EJECTOR,-,AUTOMATIC,NON-HEATED,BENDIX,DV-2,ALL TANKS,IN LIEU
19AY00	0038	R	PARKING BRAKE,AIR,MAXI,-,-,-
19FD00	0003	R	AIR COMPRESSOR,16.5 CFM,WATER,BENDIX,-
20DB00	0018	R	TRACTOR PACKAGE,CONVENIENCE,W/12 FT COILED LINES,-,-
21AR0E	0045	M	SLEEPER BOX,60" AERO,HI LEVEL TRIM,CHARCOAL
21BW0E	0002	M	HEATER & AIR COND,IN SLEEPER
21BY0E	0001	M	INSULATION PACKAGE,ARCTIC
21C30E	0001	M	EXTERIOR SLEEPER COLOR,WINDSWEPT PAINT DESIGN
21PH00	0016	D	PREP PACKAGE,TO BE INSTALLED BY KTP
22AL00	0004	R	CAB,CONVENTIONAL,DUAL HI-LEVEL TRIM,CHARCOAL
23AM00	0029	R	MIRRORS - DUAL,WESTERN,DELBAR,STAINLESS,LIGHTED/HEATED,-
23AY00	0021	R	WINDSHIELD WIPERS,AIR
23A300	0026	R	TINTED GLASS A/AROUND,-
23A800	0006	R	GRILLE,BRIGHT,-
23A900	0021	R	WINDSHIELD MOLDING,BRIGHT
23BL00	0029	R	CAB TRIM - EXTERIOR,-,CUSTOM HI-LEVEL
23BP00	0010	R	MIRROR BRACKETS,102" ARMS
23CX00	0023	R	HORNS - AIR,DUAL,HADLEY,-,DUAL BASE RECT,-
23DD0E	0001	B	SUN VISOR - EXTERIOR,FIBERGLASS
23KF00	0001	R	CHASSIS FAIRINGS,FOR 60" SLEEPER,-
24AG00	0019	R	RADIO,AM/FM STEREO CASS TAPE,-,-
24AJ00	0047	R	AIR CONDITIONING,-
24AL00	0030	R	CIGAR LIGHTER,DASH MOUNTED
24AP00	0018	R	STEERING WHEEL,21 IN DIA,-

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
24A000		0019	R	STEERING COLUMN,ADJUSTABLE			
25AJ00		0002	R	SEAT BELTS,LAP & SHOULDER			
25B300		0021	R	SEAT - DRIVER,INDIV,NATIONAL,HIBACK,CUSH-N-AIRE,AIR,CUSTOM HI-LEVEL T			
25B400		0018	R	SEAT - PASS,INDIV,NATIONAL,HIBACK,CUSH-N-AIRE,AIR,CUSTOM HI-LEVEL TRI			
26AG00		0002	R	INSTRUMENT PANEL,FULL INSTRUMENTATION			
26AN00		0012	R	GAUGES-TEMPERATURE-AXLE,-			
26AP00		0020	R	GAUGES-TEMP-TRANSMISSN,-			
26AR00		0011	R	GAUGES-TEMP-ENGINE/OIL,-			
26A200		0012	R	WARN BUZZ/LTS-ENG,LOW OIL PRESS,LOW COOL LEVEL,HIGH WATER TEMP,-			
27AB00		0017	R	LIGHTS HOOK-UP,TRAILER-MTD BACK OF CAB,-			
27AF00		0023	R	LIGHTS MARKER,BRIGHT RECT - DIETZ			
27G700		0023	R	FOG LIGHTS,-,-			
28AH00		0022	R	ALTERNATOR,MOTORCRAFT,90 AMP,-,NON-INTGL,-			
29AH00		0009	R	BATTERIES,4,12V,MOTORCRAFT,625 CCA,93 AMP,GROUP 31,STUD TYPE			
30GX00		0002	R	ENGINE,DIESEL,CATERPILLAR,3406B,PEEC,425 HP,2000 RPM,1450 FT LBS TORQ			
32AX00		0056	D	EXH,DHDVO,DU HORZ,ARGNT,- MUFFLER,W/DUAL BRT,VERT OLET UDR FRM,FRM MT			
36A500		0009	R	CLUTCH,15.5,SPICER,2-PLT,-,-,DMP CER,2 SPL,PULL,-,-,-,-,-			
37AL00		0016	R	FILTERS OIL,LUBERFINER,-,ALUM CASE,-			
37AP00		0029	R	STARTING AID,-,-,ETHER TANK TYPE			
37A100		0002	R	CRUISE CONTROL,-			
37A900		0029	R	HOSES - RAD/HTR/ENG,-,-,SILICONE,-			
37BG00		0009	R	FAN CLUTCH,BENDIX,-,-			
40AK00		0026	R	FRAME,13.3 SM,110000 PSI,SGL CHNL,STL,-,-			
43A000		0016	D	FUEL TANKS,DUAL,120 GAL,LH CYL 24" DIA,ALUM,120 GAL,RH CYL 24" DIA,AL			
46BD00		0010	R	SUSPENSION FRONT,12000 LBS,-,-,DEFL RATE 1335 LBS/IN,PARABOLIC TAPER			
47B800		0016	R	REAR SUSPENSION -TANDEM,40000 LBS,HEND,HA-400,AIR RIDE,52",-,-,T/T-A,			
48AC00		0003	R	AIR BAG DUMP VALVE,IN CAB,-,FULL AIR OPERATED			
50FM00		0001	R	TIRES FRONT,TUBELESS,RADIAL,11,X24.5,-14,GOODYEAR,UNISTEEL G159,478 R			
51FP00		0001	R	TIRES REAR,TUBELESS,RADIAL,11,X24.5,-14,GOODYEAR,UNISTEEL G167A,474 R			
52BF00		0001	R	WHEELS FRT,24.5,X8.25,10H,-,-,P/ALUM,1PC,10 HH,-,-,BSN,-,5.68, 7200 L			
53BF00		0001	R	WHEELS RR,24.5,X8.25,10H,-,-,P/ALUM,1PC,10 HH,-,-,BSN,-,5.68, 7200 LB			
56BF00		0018	R	TRANSMISSION,MANUAL,FULLER,RTO 14613,13 SPD,.87,16,1450			
57AA00		0011	R	OIL COOLER,TRANSMISSION			
59AH00		0020	R	BUMPER,FULL WIDTH,ALUMINUM,-			
60DM0E		0006	B	FIFTH WHEEL,HOLLAND,3500,24.5" AIR SLIDE,8.00",-,-,-			
60E10E		0001	B	FIFTH WHEEL SETTING,0",-			
60FA0E		0002	B	TAPERED FRAME ENDS,-			
60FE0E		0002	B	SKID RAIL RAMP,-			
60RM0E		0001	B	MUD FLAPS,-,-,WHITE POLY,-,FB27 STAINLESS BRKTS			
62AA00		0001	R	TRANSPORTATION,DRIVE AWAY			
645L00		0001	R	WARRANTY COVERAGE CODE,5L			
82AA00		0232	R	D/LINE JOINT SIZE CHART,-			
90BF00		0001	D	DRIVELINE SPEC,1810HD			
91AF00		0017	D	FRM-KD INTERMED CRSMBR,-			
91AG00		0012	D	FRAME-KD FRONT CLIPPNG,-			
91AH00		0017	D	FRM-KD INTRMED CLIPPNG,-			

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK

91A600	0007	D	EXHAUST SYSTEMS,32AX&32AV DHDVO UF B-SL				
91BC00	0007	D	FRAME-BAT BOX LOC DEL,DELETE FRAME PATTERN,-				
92AB00	0005	D	SLEEPER AIR COND,FOR MOD CTR SLPR INST.				
92AC00	0005	D	SLEEPER HEATER HOSES,FOR MOD CTR SLPR INST.				
92AD00	0002	D	SLEEPER PROVISIONS,FOR MOD CTR SLPR INST.				
92AE00	0002	D	WIRING - SLEEPER,FOR MOD CTR SLPR INST.				
92A300	0001	D	RELOCATE WASHER BOTTLE,FOR SLEEPER INSTALLAT'N				
92BB00	0001	D	SLEEPER BOX,PEDESTAL BRACKETS,-				
93BC00	0006	D	CAT/CON FOR AEROMAX 120,-				

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK

R_D:	PartNo:	Qty:	ServPart:	PartDesc:	DsoOpt:
R	BUCKS-A-DAY	1		TEST PART	
R	D7HT-1015-BUA	4		DISC & RIM ASSY WHL	
R	D7HT-1015-BYA	2	D8HZ-1015-J	DISC & RIM ASSY WHL	
R	E0HT-1015-DA	4		DISC & RIM ASY	
R	E5HT-1102-DA	1		HUB & DRUM ASY RH	
R	E5HT-1103-DA	1		HUB & DRUM ASY LH	
R	E9HT-1113-DA	2		HUB-BRK DR ASY RR WHL RH	
R	E9HT-1114-DA	2		HB & BRK DRM ASY-RR WHL L	
R	E7HT-1124-AA	4		WSHR-RR WHL BRG NUT LK	
R	E5HT-1131-CA	2		CAP-FRT HUB GRSE-OIL	
R	D5HA-1132-AA	20	D5HZ-1132-A	NUT-RR WHL INR CAP-RH	
R	D5HA-1133-AA	20	D5HZ-1133-A	NUT-RR WHL INR CAP-LH	
R	BB-1134-	20	BB-1134-	NUT-DISC WHL-RH THD	
R	BB-1135-	20	BB-1135-	NUT-DISC WHL-LH THD	
R	TAKAA-1142-A	32	B8QH-1142-B	ADAPTER-RR WHL HUB STUD	
R	E9HT-1144-AA	4	E9HZ-1144-A	GSKT-RR AX SHFT	
R	F0HT-1153-CA	2		GSKT-FRT HB GRSE CAP	
R	D7HT-1173-BA	4		WIPER-RR AX OIL INR	
R	D5HA-1175-AA	4		RET ASY-RR WHL GRSE INR	
R	E7HT-1190-AA	2	E7HZ-1190-A	RET ASY FRT WHL HUB OIL	
R	C4TA-1216-B	2	C4TZ-1216-A	CONE & ROLER ASY FRT OTR	
R	E7HT-1216-AA	2		CONE & RLR ASY FRT WHL OT	
R	TAJAA-1240-A	4	B8QH-1240-B	CONE & ROLLER ASY OTR	
R	D7HA-1244-AA	4	D7HZ-1244-A	CONE & ROLLER ASY INR	
R	D5HA-1508-GA0208	8		CASING - TIRE 11R24.5 (G)	
R	D5HA-1508-GA0202	2		CASING - TIRE 11R24.5 (G)	
R	E9HT-2010-AC	1		BRAKE ASSY-FRONT-RH	
R	E9HT-2011-AC	1		BRAKE ASY-FRONT L.H.	
R	E9HT-2025-EC	2	E9HT-2025-EC	CHAMBER ASY-FRT WHL	
R	E1HT-2063-BA	1	E1HZ-2063-A	RESVR ASY BRK L.H	
R	E1HT-2063-CA	1	E1HZ-2063-B	RESVR ASY-BRK R.H.	
R	E9HT-2063-AA	1	E9HZ-2063-B	RESVR ASSY-BRK	
R	E2HT-2074-AA	2	E1HZ-2074-A	CONN RR WHL BRK TUB	
R	E7HS-2074-JA	4	FOHZ-2074-A	CONN-RR WHL BRK TUBE	
R	E2HT-2078-BA	2	D5HZ-2078-D	TUB & HOSE ASY	
R	E5HT-2084-BA	4	C8HZ-2084-A	CLMP ASY-RESVR	
R	E9HT-2209-JC	2		BRAKE ASSY-REAR RH	
R	E9HT-2210-JC	2		BRAKE ASSY-REAR LH	
R	E9HT-2225-BC	2	E9HZ-2225-B	CHAMBER AY-RR WHL BRK-AIR	
R	E9HT-2225-DC	2	E9HZ-2225-D	CHAMBER AY-RR WHL BRK AIR	
R	E2HT-2282-AA	1	EOHZ-2282-A	HOSE ASSY RR WHL BRK	
R	E9HT-2308-BB	2	E9HZ-2308-B	SLACK ADJUSTER /AUTOMATIC	
R	E9HT-2314-BB0666	4		SLACK ADJUSTER /AUTOMATIC	
R	C8TA-2457-B	1	C7TZ-2457-B	PAD-BRK PDL PLT CL	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E8HT-2467-AA		1	E8HZ-8001508-A		BRKT BRK & CL PDL ASY	
R	EDE9HT-2468-CA		1			BRKT-BRAKE PEDAL	
R	E7HT-2557-AA		1	E7HZ-2557-A		GUAGE-AIR PRESS	
R	D2HB-2573-AA		1	DOHZ-2573-A		BUZ ASSY-BRK LOW AIR PRS	
R	E7HT-2573-AC		1	E7HZ-2573-A		ENG. WARNING	
R	E4HT-2885-AA		1	E4HZ-2885-A		GOVERNOR ASY COMPR	
R	E5HT-2902-AA		1	E6HZ-2902-A		BRKT-COMP SUPT	
R	FOHT-2917-BJA		1			TUBE ASY - COMP DISCHARGE	
R	D5TA-2917-JA		1	D5TA-2917-JA		TUBE ASY - COMPRESSOR DIS	
R	E3HT-2940-BA		1	D9HZ-2940-A		REINF GLAD HND BRKT	
R	E9HT-3010-AA		1	E9HZ-3010-A		FRNT AX I/BEAM	
R	D3HA-3020-AA		2	D5HZ-3020-A		BUMPER ASY-FRT AXLE	
R	E9HS-3105-EA		1			12K SPDL FRT WHL RHA-BAMM	
R	E9HT-3105-AB		1	E9HZ-3105-A		SPINDLE ASY-R.H.	
R	E9HS-3106-GA		1	E9HS-3106-GA		12K SPDL-FRT WHO LHSY RHM	
R	E9HT-3106-AB		1	E9HZ-3106-A		SPINDLE ASY-L.H.	
R	E9HT-3113-AA		4	E9HZ-3113-A		SPNDL-CAP	
R	D5HA-3115-BA		2			PIN SPDL	
R	D5TA-3122-AB		2	D6TZ-3122-A		LOCK-PIN	
R	D5TA-3122-BA		2	D5TZ-3122-D		LOCK PIN	
R	D1HA-3123-AA		2			BRG ASY-FRT WHL SPDL PIN	
R	D3HA-3125-AA		4			SE-SPDL PIN DIST	
R	D4HA-3125-AA		4			SE SPDL PIN DST	
R	E7HT-3130-CB		1	E7HZ-3130-C		ARM STRG SPDL RH	
R	E7HT-3131-CB		1	E7HZ-3131-C		ARM STRG SPDL LH	
R	TGCB-3138-A		3			KEY-STNG SPDL ARM	
R	E7HT-3146-KA		1	E7HZ-3146-K		ARM-STNG SPDL DG LNK	
R	E5HT-3280-HA		1	E4HZ-3280-B		ROD ASSY-STRG SPINDLE ARM	
R	F1HT-3304-VA		1	F1HZ-3304-J		ROD ASY-STNG PTMN TO IDLE	
R	F1HT-3490-BA		1	F1HZ-3490-C		BRACKET - P/S RESERVOIR	
R	E5HT-3530-AA		1	E5HZ-3530-A		SHRD-STNG COL	
R	E9HT-3531-AA		1	FOHZ-3A697-A		RESERVOIR ASSY - P/S	
R	F1HT-3590-LA		1	F1HZ-3590-G		ARM-STNG GR PTMN	
R	FOHT-3600-AA		1			STEERING WHEEL - SPORT 21	
R	E7HT-4254-AA		8	E7HZ-4254-A		NUT OUTER	
R	E3HT-4484-BA		1	E3HZ-4484-A		VLV ASY-PWR DIV DIFF LKOU	
R	C1TT-4487-A		2			BRACKET	
R	C1TT-4487-B		2			BRKT TUB ASY	
R	D7HA-4568-BA		2			REINF-RR AX TOR ARM BRKT	
D	E8HT-4602-HNA		1			DRV/SHT ASY-1810 JT	DL: J05
D	E8HT-4817-KVA		1			CPL/SHT ASY-1810 JT	DL: J03
D	E9HS-4831-AA		1	E9HZ-4831-E		SUPT PLT-CPL/SHT	DL: 062J01
R	E9HT-4851-LA		1	E9HZ-4351-C		YK ASY-U/JT RR AX END 181	
R	E9HT-4858-BA		1	E9HZ-4465-A		YOKE ASY-RR AX END-1710	
R	E8HS-4962-YA		4	E9HZ-4612-B		TORQUE. ROD ASSY-FRNT	
R	E9HS-4962-DA		2	E9HZ-4612-J		ARM ASY-RR AX TORQUE 21.0	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E3HT-4964-AA		1			DRV/SHT ASY-RR INTR AX-17	
R	F1HT-5000-CR9804		1			SPEC-FRAME ASY	
R	F1HT-5000-CR6400		1			SPEC-FRAME ASY	
R	F1HT-5000-CR6557		1			SPEC-FRAME ASY	
R	F1HT-5000-CR7000		1			SPEC-FRAME ASY	
R	F1HT-5000-CR7600		1			SPEC-FRAME ASY	
R	F1HT-5000-CR8001		1			SPEC-FRAME ASY	
R	F1HT-5000-CR8201		1			SPEC-FRAME ASY	
R	F1HT-5000-CR9400		1			SPEC-FRAME ASY	
R	F1HT-5000-CR9602		1			SPEC-FRAME ASY	
R	F1HT-5000-CR4001		1			SPEC-FRAME ASY	
R	F1HT-5000-CR9818		1			SPEC-FRAME ASY	
R	F1HT-5000-CR9819		1			SPEC-FRAME ASY	
R	F1HT-5000-CR9820		1			SPEC-FRAME ASY	
R	F1HT-5000-CR9823		1			SPEC-FRAME ASY	
R	F1HT-5000-CR9827		1			SPEC-FRAME ASY	
R	F2HT-5000-CR4405		1			SPEC-FRAME ASY	
R	F2HT-5000-CR4452		1			SPEC-FRAME ASY	
R	F1HT-5000-CR9560		1			SPEC-FRAME ASY	
R	F1HT-5000-CR0251		1			SPEC-FRAME ASY	
D	FOHS-5000-CD6454		1				91AH0000170
D	FOHS-5000-CD9454		1				91AH0000170
D	FOHS-5000-CD9801		1				92BB0000010
D	F1HS-5000-CD9002		1				91A60000070
R	F1HT-5000-CR0018		1			SPEC-FRAME ASY	
R	F1HT-5000-CR0101		1			SPEC-FRAME ASY	
R	F1HT-5000-CR4050		1			SPEC-FRAME ASY	
R	F1HT-5000-CR0234		1			SPEC-FRAME ASY	
D	F1HT-5000-CR0273		1			SPEC-FRAME ASY	91AF0000170
R	F1HT-5000-CR0290		1			SPEC-FRAME ASY	
R	F1HT-5000-CR0300		1			SPEC-FRAME ASY	
R	F1HT-5000-CR2027		1			SPEC-FRAME ASY	
R	F1HT-5000-CR3000		1			SPEC-FRAME ASY	
R	F1HT-5000-CR3202		1			SPEC-FRAME ASY	
R	F1HT-5000-CR5012		1			SPEC-FRAME ASY	
R	F1HT-5000-CR0200		1			SPEC-FRAME ASY	
R	F1HT-5015-JBA		1			SIDEMEMBER-FRAME-RH	
R	F1HT-5016-JBA		1			SIDEMEMBER-FRAME-LH	
R	F1HT-5019-BA		1	F1HZ-5019-B		CROSSMEMBER ASY - FRAME F	
R	E9HT-5025-AA		1	FOHZ-5025-A		C/M ASY-#2 RR BODY SUET	
D	E5HT-5028-AA		2	DOHZ-5028-A		CMBR-FRM INTERMEDIATE	91AF0000170
R	FOHT-5036-BA		1			C/M ASY-FR #5	
R	F1HT-5045-AB		1	F1HZ-5045-A		REINF-FR S/M LH	
R	F1HT-5086-CB		1	F1HZ-6A067-C		BRACKET-ENG SUPT TO FRAME	
R	E1HT-5086-FA		1	D4HZ-6A067-B		BRKT-ENG SUPT TO FR RH	
R	F1HT-5087-BA		1	F1HZ-6A067-E		BRKT-ENG SUPT LH	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
D	E8HS-5225-GA		2	E8HS-5225-GA		MUFFLER 195-1140	91A60000070
R	F1HT-5246-LA		1	F1HZ-5246-U		PIPE ASY - MFLR INLET	
D	E1HS-5255-BVA		2	E1HS-5255-BVA		PIPE	91A60000070
D	E7HS-5255-JA		2	E7HS-5255-JA		PIPE	91A60000070
D	F1HS-5255-BA		1			PIP-MFLR OLET FRT RH	91A60000070
D	F1HS-5255-DA		1			PIP-MFLR OLET FRT RH	91A60000070
D	E1HT-5270-GA		6	E1HZ-5A231-F		CLAMP ASY	91A60000070
D	E1HT-5270-AA		8	E1HZ-5A231-B		CLMP ASY	91A60000070
D	E7HS-5289-AA		2			BRACKET	91A60000070
R	F1HT-5291-BA		1	F1HZ-5291-A		BRKT-MFLR INLET PIPE	
R	F1HT-5310-FB		2	F1HZ-5310-J		SPG ASY-FRT 12K 58" TL	
R	F1HT-5335-AA		2	F1HZ-5340-J		BRKT ASY-FRT SPG SHKL	
R	F1HT-5340-EA		1	F1HZ-5340-K		BRKT-FRT SPG RH	
R	F1HT-5341-AA		1	F1HZ-5340-H		BRKT-FRT SPG LH	
R	E0HT-5455-EA		4			U-BOLT FRT SPRG	
R	D5HA-5458-AA		4	D5HZ-5458-A		SPCR-FRT SPRG BLT	
R	F0HT-5580-AA		4			SPRNG ASY-RR SUSP AIR	
R	E9HT-5705-CA		8	E9HZ-5705-B		U-BOLT-RR SPRING 7/8-14	
R	E7HS-5708-AA		4	E9HZ-5708-A		PAD-RR SPRNG BOLT	
R	E9HT-5785-AA		4	E9HZ-5775-B		BRKT-RR SPRNG FRNT.	
R	E9HT-5788-EA		2	E9HZ-5793-A		SPRING SEAT-RR SPRING RR.	
R	E8HS-5789-AA		2	E9HZ-5793-B		SPRING SEAT-FWD. RR	
R	E8HS-5796-AA		8	E9HZ-5796-A		AXLE BOTTOM CAP ASSY.	
R	D7HA-5883-BA		2	D8HZ-5883-A		BRKT-RR AX TOR ARM TO FR	
R	E7HS-5884-BA		2	E9HZ-5884-A		BAR-RR SUSP SUPT	
R	E7HS-5889-BA		4	E9HZ-5889-J		BEAM ASY-RR SUSP SUPT	
R	E7HS-5990-AA		4	E9HZ-5990-A		BRKT ASY-RR SPRNG	
R	F1HT-6007-BMAL7E0		1			ENGINE ASY-AS PURCHASED(4	
R	E5HT-6028-CA		1	E5HZ-6028-B		BRKT-ENG FRT SUPT	
R	D3HA-6038-AA		2	D3HZ-6038-A		INSULATOR ASY-ENG FRT SUP	
R	D0HA-6068-B		2			INS ASY RR SUPT	
R	D4HA-6096-AA		1	D4HZ-6096-A		BRKT-ENG SUPT RR RH	
R	E0HT-6346-AA		1			DECAL ENG STRT INST DSL	
R	48ZF-6590-B		1			PLASTIC BAG	
R	E7HT-6728-BA		2	E7HZ-6728-A		BRKT OIL FLTR MTG	
R	EDE8HT-6750-GB		1	DE8HT-6750-GB		IND ASY-OIL LVL	
R	EDE8HT-6750-TA		1	F1HZ-6750-C		IND ASY-OIL LVL	
R	F0HT-6754-DA		1			TUBE ASY-OIL LEVEL INDICA	
R	E4HT-6974-DA		1			MANUAL-ENG OPER INSTRU	
R	F0HT-7003-DYA		1			TRANS & EXT ASY RTO-1461	
R	48ZF-7057-		1			OWNERS MANUAL PALSTIC BAG	
R	48ZF-7197-		2			PROTECTOR-CARPET	
R	F0HT-7201-CA		1			HSNG ASY - TRANS GR SHIFT	
R	F0HT-7213-DA		1			KNOB ASY-TRANS CONTR SEL	
R	48ZF-7357-30B		2			COVER FRONT SEAT CUSHION	
R	D0HA-7506-D		1			SHAFT-CL & BRK PDL PVT	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	D0HA-7508-A		4			BUSHING-CL PDL SHFT	
R	E1HT-7510-AA		1	E1HZ-7510-A		SHFT-CL REL	
R	E6HT-7510-AA		1	E7HZ-7510-C		SHFT-CL REL	
R	E1HT-7511-DA		1	E1HZ-7511-B		LEVER-CLUTCH RELEASE SHAF	
R	E8HT-7519-CA		1	E8HZ-7519-A		PDL ASSY-CL	
R	E7HT-7522-AA		1	E7HZ-7522-A		BRKT-CL REL LVR	
R	D0HA-7523-Y		1			SPG-CL REL RETR	
R	D0HA-7530-AM		1			ROD ASY-CL REL	
R	E1HT-7530-AA		1	E1HZ-7521-A		ROD ASY CL REL	
R	C3TS-7541-A		1	C6TZ-7515-A		LVR-CLUTCH RELEASE	
R	D0HA-7542-N		1			BRKT-CL REL LVR RETR SPG	
R	E8HT-7550-AA		1	E8HZ-7550-B		DISC ASY.CL FRT.	
R	E8HT-7563-AA		1	E8HZ-7563-A		PL. & CVR ASY CL. PRESS.	
R	C1TT-7590-A		1	C1TT-7590-A		SHFT-CL REL STUD	
R	C2TA-7590-A		1	C2TZ-7590-A		SHFT-CL REL STUD	
R	C3TA-7600-B		1			BEARING ASY-CL PILOT	
R	F1HT-7890-VA		1			HOS ASY-TRANS OIL COOL	
R	F1HT-7890-UA		1			HOS ASY-TRANS OIL COOL	
R	F1HT-7890-HA		1			HOS ASY-TRANS OIL COOL	
R	F1HT-7890-GA		1			HOS ASY-TRANS OIL COOL	
R	CSE-7972-TX291		1			1991 WARRANTY INFO. BOOKL	
R	F1HT-8009-ACA		1			RAD & SUPT ASY, L/LLS W/3	
R	E8HT-8100-BA		1	E6HZ-8100-D		CAP ASSY RAD	
R	F1HT-8146-EB		1	F1HZ-8146-B		SHROUD-FAN	
R	F1HT-8150-BC		1			RAD GRILLE	
R	E5HT-8188-AA		1	E1HZ-8188-A		PNL ASY-RAD GRL LWR	
R	E5HT-8190-AA		1	E1HZ-8190-A		PNL ASY-RAD GRL UPR	
R	F1HT-8260-AEA		1	F1HZ-8260-R		HOSE-RAD UPPER (SILICONE)	
R	F1HT-8260-RB		1	F1HZ-8260-L		HOSE-RAD UPR (SILICONE)	
R	E9HT-8260-RA		1	E9HZ-8260-G		HOSE-RAD UPR /SILI/	
R	E9HT-8276-BA		2	E9HZ-8276-F		HOSE-RAD TO SPLY TNK VENT	
R	F1HT-8276-BB		1	F1HZ-8276-B		HOSE-RAD TO SPLY TNK VENT	
R	F1HT-8286-AFA		1	F1HZ-8286-L		HOSE - RADIATOR LOWER	
R	F1HT-8286-TA		1	F1HZ-8286-BG		HOSE ASY-RAD LWR (SILICON	
R	E9HT-8287-FB		3	E9HZ-8287-B		CLAMP-RAD HOSE	
R	E9HT-8287-EB		1	E9HZ-8287-C		CLAMP-RAD HOSE	
R	F1HT-8290-ED		1			PIPE 10109469 3406	
R	E7HT-8566-AB		1	E7HZ-8566-A		TEE ASSY - WATER BYPASS	
R	E9HS-8600-CA		1	FOHZ-8600-E		FAN ASY-ENG COOLING	
R	F1HT-8600-LA		1	F1HZ-8600-H		FAN ASY-ENG COOLING	
R	F1HT-8620-VA		1	F1HZ-8620-H		BELT DRIVE	
R	E2HT-8653-AA		2	E2HZ-8653-B		DECAL-FAN CLUTCH DRIVE	
R	F1HT-9002-TA		1	F1HZ-9002-T		TNK-FUL 120 GAL. ALUM. R/	
R	F1HT-9002-UA		1	F1HZ-9002-U		TNK-FUL 120 GAL. ALUM. L/	
R	E3HT-9046-CA		6	E1HZ-9046-E		BRKT-FU TK SUPT	
R	F1HT-9054-DC		4	F1HZ-9054-D		STRAP ASY-FUEL TANK	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	F1HT-9054-EA		2	F1HZ-9054-E		STRAP ASY-FUEL TANK	
R	F1HT-9054-ED		2	F1HZ-9054-E		STRAP ASY-FUEL TANK	
R	F1HT-9054-FA		1	F1HZ-9054-F		STRAP ASY-FUEL TANK	
R	D7HT-9067-DA		6			INSULATOR	
R	E2HT-9071-AA		2	E1HZ-9071-B		SPCR FU/TNK MTNG	
R	E2HT-9071-BA		4	E1HZ-9071-A		SPCR-FU/TNK BRA	
R	E6HT-9155-AA		1	E6HZ-9155-E		FUEL FILTER (PRIMARY)	
R	E9HT-9180-AA		1	FOHZ-9180-C		BRACKET-FUEL FILTER	
D	E1HT-9189-AA		4	E1HZ-9189-A		VLV ASY	92AC0000050
R	E7HT-9273-AA		1	E7HZ-9273-E		INDICATOR ASY-OIL PRESSUR	
R	E1HT-9275-AA		1	E1HZ-9275-A		SENDER ASSY-FUEL TANK	
R	C1TF-9276-C		1	C1TF-9276-C		GSKT-FU LEVEL SENDER	
R	E7HT-9280-BA		1	E7HZ-9280-B		INDICATOR ASY-FUEL LEVEL	
R	C3TA-9338-C		1	C3TA-9338-C		BRKT	
R	F1HT-9600-BB		1	F1HZ-9600-B		CLNR ASY ENG AIR	
R	E0HT-9735-AA		1			PDL ASY-ACEL	
R	E2HS-9737-CA		1	E4HZ-9737-A		SPRING-ACCEL	
R	E2HS-9737-DA		1	E4HZ-9737-B		SPRING-ACCEL	
R	FOHT-9737-DA		2			SPG-ACEL SHFT RET	
R	FOHT-9741-AB		1			BRKT-RETURN SPRING	
R	FOHT-9741-EA		1			BRKT-RETURN SPRING	
R	E4HT-9741-BA		1	E4HZ-9741-D		BRKT ACEL RETR SPG	
R	FOHT-9798-GA		1			ARM - ACCEL PDL	
R	E4HT-9824-BA		1	E4HZ-9824-C		BRKT HND THROT CONT	
R	E4HT-10159-AA		1	E4HZ-10156-A		BRACKET-ALTERNATOR ADJUST	
R	FOHT-10239-DA		1			BRKT ASSY-ALT MNTG	
R	FOHT-10300-LA		1			ALTERNATOR ASY-15V-90 AMP	
R	E4TF-10316-AA		1	E4TF-10316-AA		REG ASY-ALTERNATOR	
R	F0TU-10316-AA		1			REG ASY-ALTERNATOR	
R	E6HT-10655-BA		4			BATTERY ASY-93 A.H. MOTOR	
R	D9HT-10718-AB		2	D8HZ-10718-C		CLAMP ASSY	
R	E3HT-10733-AA		2	E3HZ-10733-A		GROMMET-BATTERY	
R	E0HT-10756-AA		4			BOLT	
R	E8HT-10817-AD		1	E8HZ-10817-B		W/A-INSTR CLSTR FEED	
R	E3HT-10852-DA		1	E3HZ-10852-A		BEZEL	
R	E7HT-10852-AA		1	E7HZ-10852-A		BZL-I/CLSTR CTROL	
R	E7HT-10883-AA		1	E7HZ-10883-C		156199 TRANS TEMP	
R	E7HT-10883-BA		1	E7HZ-10883-B		INDICATOR ASY-TEMP-WATER	
R	E9HT-10884-BA		1	FOHZ-10884-A		SENDER ASY-WATER TEMP IND	
R	FOHT-11001-AB		1			MOTOR ASY-STARTER	
R	E7HT-11450-AA		1	SW-1507-BDP		RELAY ASY-STR MTR	
R	E9HT-11500-AA		1	E9HZ-11500-A		SW ASY-STR PUSH/BTN	
R	D7HT-11572-AA		1	DOTZ-11572-A		SW ASY-IGN	
R	C9AB-11584-B		1	C9AZ-11584-A		BEZEL INGITION SWITCH	
R	FPS-12156-91		1			1991 OWNERS MANUAL	
D	F1HS-12440-AA		1			TUB ASY-HTR HOT WTR	92AC0000050

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	FOHT-12638-AB		1			W/A STARTER CIRCUIT JUMPE	
R	FOHT-13005-AA		1			HEADLAMP ASY R.H.	
R	FOHT-13006-AA		1			HEADLAMP ASY L.H.	
R	E6AB-13007-BA		2			BLB ASY HD/LMP/HIGH BEAM/	
R	E6AB-13007-AA		2			BLB ASY HD/LMP/LOW BEAM/P	
R	D7OB-13018-AA		4	D7OZ-13015-A		RING ASY HD/LP BLB RET	
R	D7HT-13031-AA		4	D8HZ-13031-A		SPRING HD/LP RING	
R	D7OB-13037-AA		1	D7OZ-13118-A		RING HD/LP ADJ	
R	D7OB-13047-AA		1	D7OZ-13119-A		RING HD/LP ADJ	
R	E1HT-13052-AD		1	E1HZ-13064-D		DR-HD LP LH	
R	E8HT-13052-BB		1	E8HZ-13064-C		DR-HD/LP R.H.	
R	E8HT-13064-AB		1	E8HZ-13064-B		DR-HD/LP LH.	
R	E1HT-13064-AD		1	E1HZ-13064-C		DR-HD LP RH	
R	E8HT-13076-CB		1	E1HZ-13076-A		W/A HD/LP LEADS RH	
R	F1HT-13105-AC		1	F1HZ-13076-A		WIRING ASSY - HEADLAMP LE	
R	D7OB-13116-AA		1	D7OZ-13118-B		RING HD/LP ADJ	
R	D7OB-13117-AA		1	D7OZ-13119-B		RING HD/LP ADJ	
R	D4TB-13350-AA		1	D4TZ-13350-A		FLASHER ASY-TURN SIGNAL	
R	E0HT-13404-AA		1			LENS ASY RR RH	
R	E0HT-13405-AA		1			LENS ASY RR LH	
R	D7HA-13406-AA		1	D8HZ-13406-A		BRKT RR LIC	
R	C8TB-13465-B		2	CLB-1157-DP		BLUB ASY #1157	
R	C3AB-13466-B		15	CLB-1895-DP		BULB ASY-LP 2.0 CP 12V S	
R	E0TB-13470-BA		2			BRKT RR LP RH	
R	E3HT-13480-AA		1			SW ASY-STOP LP	
R	E8HT-13621-AA		8	D8HZ-13621-B		SCKT & WIR ASY INST PNL L	
R	D2HB-13655-AA		1	D3HZ-13655-A		BRKT-H/LAMP DIM CONT MTG	
R	E7HT-13740-AA		1	E7HZ-13740-A		SW ASY INST PNL LP	
R	E8HT-13776-AA		1	EOTZ-13776-E		LP ASY INT	
R	D2LB-13783-AB		1	D2LY-13783-E		LENS-INT LP/BUG-EYE LP	
R	F1HT-13802-AA		1	F1HZ-13832-B		HORN ASSY - LOW PITCH (12	
R	E8HT-13828-AA		1			BRKT-HORN MTG	
R	E1HT-13828-AA		1			BRKT-HORN MNTG AIR	
R	D7HT-13910-AB		1	D8HZ-13910-B		VLV ASY-HORN AIR CONT	
R	E1HT-13910-AA		1	E1HZ-13910-A		VLV ASY-HORN AIR CONTROL	
R	E7HT-13932-BA		2	E7HZ-13932-C		PAD-HORN MNTG BRKT	
R	E7HT-13932-AA		2	E7HZ-13932-A		PAD-HORN MNTG BRKT	
R	E7HT-13933-CA		2	E7HZ-13933-C		PLATE-HORN MTG REINF	
R	E8HT-14088-AA		4	E8HZ-14677-A		RELAY ASY-ACCESSORY	
R	F1HT-14290-DD		1			W/A DASH PNL TO HEADLAMP	
R	F1HT-14300-ASA		1	F1HZ-14300-H		CABLE ASSY - BATT TO STR	
R	D9HT-14300-BAB		1			CABLE ASSY BATT TO STR	
R	D9HT-14300-CHA		1	D8HZ-14300-A		CABLE ASY-BATT TO STR MTR	
R	F1HT-14300-ARA		1	F1HZ-14300-G		CABLE ASSY - BATT TO STR	
R	F1HT-14301-BKA		1	F1HZ-14301-X		CABLE ASSY - BATTERY TO G	
R	FOHT-14301-AUB		1			CABLE ASSY - BATTERY TO G	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	F1HT-14301-AUA		1	F1HZ-14301-T		CABLE ASSY - BATTERY TO G	
R	FOHT-14301-AVB		1			CABLE ASSY - BATTERY TO G	
R	C8TB-14303-C		1			CABLE ENG GND	
R	E9HT-14303-AA		1	E9HZ-14303-A		CABLE ASY - ENGINE GROUND	
R	F1HT-14305-UC		1	F1HZ-14305-H		W/A ALT RECTIFIER SYSTEM	
R	F1HT-14401-VE		1	F1HZ-14401-K		WIRING ASSY - MAIN	
R	F1HT-14405-BLA		1	F1HZ-14405-AE		W/A REAR LAMP (75AF)	
D	D0HB-14448-D		3			BLK ASY JCT	92AE0000010
R	E8HT-14448-AA		1	E8HZ-14448-A		BLOCK ASSY-JUNCTION	
R	FOHT-14448-AA		1			BLOCK ASY-JUNCTION	
R	FOHT-14448-BA		1			BLOCK ASY-JUNCTION	
R	D0HB-14448-C		1			BLK ASY JCT	
D	E7HS-14526-BA		4			1741-3081V 12V 30 AMP	92AE0000010
R	D7HT-14526-BA		1	D8HZ-14526-B		CIRC BRKR ASY 22A	
R	E8HT-14603-AA		1			GROM-WIR	
R	D0HB-14672-C		1			WIR ASY HRN CONN	
R	F1HT-14779-AB		2	F1HZ-14779-A		HARNESS ASSY-TURN SIGNAL	
R	E2HT-14806-AA		1	E4HZ-14806-A		SW ASSY-ENG FAN CONTR	
R	D3HB-15052-AA		1	D3HZ-15052-B		KB & ELEM ASY C/LTR	
R	D3HB-15055-AA		1	D3HZ-15055-A		SCKT & RET ASY CGR LTR	
R	C3TB-15072-A		1	C3TZ-15072-A		LAMP ASY-C/LTR	
R	F1HT-15237-AC		1	F1HZ-15237-A		W/A - FOG LAMP FEED	
R	F1HT-15244-AC		1	F1HZ-15244-A		W/A - ROAD LAMP LEAD	
R	E5HT-15442-AA		5	E7HZ-15442-A		LP ASY-MARKER	
R	D3TB-15443-AB		3	D3TZ-15443-C		SWITCH ASSY	
R	E2HS-15443-AA		1	E2HZ-15443-A		SWITCH ASY-MARKER LAMPS	
R	FOHT-15443-BA		1			SWITCH ASY - MARKER LAMP	
R	E7HT-15451-AA		5	E7HZ-15451-A		GASKET-MARKER LAMP BODY	
R	EOHT-15517-AA		1			BRKT	
R	E27B-15520-AC		1	E3TZ-15520-A		SW ASY-BK/UP LP	
R	FOHT-15525-CC		1			W/A-B/U LP SW TO RR LAMP	
R	F1HT-16000-AA		1	F1HZ-16000-B		FRT END ASY (HN72 HWY TRA	
R	F1HT-16005-DB		1			FNDR ASY RH (HN72 W/FRGS)	
R	F1HT-16006-DB		1			FNDR ASY LH (HN72 W/FRGS)	
R	F1HT-16264-AA		1	F1HZ-16264-A		BRKT-FRT WHL RR SPL SHLD	
R	F1HT-16265-AA		1	F1HZ-16265-A		BRKT FRT WHL RR SPL SHLD	
R	F1HT-16308-AA		2	F1HZ-16308-A		SEAL - FRT FNDR RH	
R	F1HT-16449-AB		1	F1HZ-16449-A		SPRING ASSY HOD REL ASST	
R	E2HT-16575-AA		2	DOHZ-16575-A		BRKT RNG BRD BRA RR	
R	E2HT-16586-BA		1	E1HZ-16586-A		BRKT FRT WHL SPLS SHLD (R	
R	E2HT-16587-AA		1	E1HZ-16586-B		BRKT FRT WHL SPLS SHLD (L	
R	E5HT-16637-AA		1	E6HZ-16637-B		ORNAMENT-BDY FRT	
R	E9HT-16637-BA		1	E6HZ-16637-A		ORN BDY FRT	
R	E5HT-16655-AA		2	E6HZ-16A668-A		SCRN ASY-HOD OPNG	
R	F1HT-16700-AA		2	F1HZ-16700-A		LATCH ASY-HOOD	
R	E8HT-16738-AB		1	E8HZ-16738-A		INSUL-HOOD SOUND FRNT R.H	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E8HT-16738-BB		1	E8HZ-16738-C		INSUL HOOD SOUND RR	
R	F1HT-16738-AB		1	F1HZ-16738-A		INS HD SND	
R	F1HT-16738-BA		1	F1HZ-16738-E		INS HD SND RH	
R	F1HT-16738-CA		1	F1HZ-16738-C		INS HD SND RH	
R	F1HT-16746-AA		1	F1HZ-16738-D		INSUL HOOD SOUND RR LH	
R	E8HT-16746-AB		2	E8HZ-16738-D		INSUL HOOD SOUND RR	
R	E8HT-16753-AB		1	E8HZ-16738-B		INSUL-HOOD SOUND FRNT L.H	
R	F1HT-16753-BA		1	F1HZ-16738-G		INS HD SND LH	
R	E8HT-16753-BB		1	E8HZ-16738-E		INSUL-HOOD SOUND RR L.H.	
R	F1HT-16753-AA		1	F1HZ-16738-H		INS HD SND LH	
R	D0HB-16774-A		2			SUPT ASY HOOD LATCH	
R	F1HT-16800-AA		1	F1HZ-16796-A		HGE ASY-HOOD - RH	
R	E2HT-16800-AA		1	E3HZ-16796-A		HINGE ASY-HOD RH	
R	F1HT-16801-AA		1	F1HZ-16797-A		HGE ASY HD LH	
R	E2HT-16801-AA		1	E3HZ-16797-A		HINGE ASY-HOD LH	
R	D0HB-16874-A		2			PLATE HOOD CAT	
R	D0HB-17016-D		1			SUPT ASY R/V O/S MIR UPR	
R	D0HB-17059-D		1			SUPT ASY R/V O/S MIR LWR	
R	FOHT-17255-AA		1			SPEEDOMETER ASY-MPH GREEN	
R	E7HT-17259-AA		1			COVER-SPEEDO /TAPE/	
R	FOHT-17345-CA		1			MAGNET ASY-SPEEDOMETER	
R	E8HT-17360-AA		1	E8HZ-17360-A		TACHOMETER ASY ELECT	
R	C4ZB-17450-C		2	C5ZZ-17531-A		CLIP W/SHLD WPR ARM	
R	E2HT-17470-AA		1			CONTR ASY W/S WPR	
R	D0HB-17504-E		1			MOTOR ASY W/SHLD WIPER AI	
R	D0HB-17526-B		2			ARM ASY-W/WIPER	
R	D0HB-17528-B		2			BLD ASY W/S WPR	
R	D3HB-17532-AA		1	D3HZ-17566-A		ARM & PIVOT SHAFT ASY W/S	
R	D3HB-17533-AA		1	D3HZ-17567-A		ARM & PVT SHFT ASY W/S WP	
R	D3HB-17610-AA		1	DOHZ-17618-A		RESERVOIR ASY-W/SHLD WSHR	
R	D0HB-17664-A		1			PUMP ASY-W/SHLD WSHR	
R	D0HB-17666-B		2			JET ASY-W/S WSHR	
R	F1HT-17750-DC		1	F1HZ-17757-C		BUMPER ASY-FRONT	
R	F1HT-17752-BB		1	F1HZ-17752-A		BRKT FRT. BUMPER RH	
R	E7HT-17752-AB		1	E7HZ-17752-A		BRACKET FRT BUMPER RH	
R	F1HT-17752-BA		1	F1HZ-17752-A		BRKT FRT. BUMPER RH	
R	E7HT-17753-AB		1	E7HZ-17753-A		BRKT FRT BMPR LH	
R	F1HT-17753-BA		1	F1HZ-17753-A		BRKT FRT BMPR LH	
R	F1HT-17753-BB		1	F1HZ-17753-A		BRKT FRT BMPR LH	
R	E8HT-17757-HA		1	E7HZ-17757-A		BUMPER-FRNT STEEL	
R	F1HT-18045-HB		2	F1HZ-18124-E		SHK ABS ASY-FRT	
R	FOHT-18080-AA		4			SHK ABS ASY-RR	
R	F1HT-18112-DB		1	F1HZ-18112-C		BRKT ASY-FRT SHK ABS LWR-	
R	F1HT-18113-DB		1	F1HZ-18113-C		BRKT ASY-FRT SHK ABS LWR	
R	F1HT-18183-AA		1	F1HZ-18183-A		BRKT ASY-FRT SHK ABS UPR	
R	F1HT-18184-AA		1	F1HZ-18184-A		BRKT ASY-FRT SHK ABS UPR	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	C1TT-18197-A		8	C1TT-18197-A		BUSHING-SHK ABS RUBBER IN	
R	PMF1HT-18471-AA		1			CHMBR ASY HTR & A/C PLENU	
R	E1HT-18495-DA		1	D1HZ-18495-B		VALVE ASY-HTR WTR CONTR	
R	F1HT-18663-EB		1	F1HZ-18663-G		TUBE ASY HTR WTR RETURN	
D	FOHS-18663-DA		1			TUB ASY-HTR WTR OLET/LETR	92AC0000050
D	F1HS-18663-AA		1			TUB ASY-HTR WTR OLET	92AC0000050
D	F1HS-18696-AA		1	F1HS-18696-AA		TUB ASY-HTR WTR INLT	92AC0000050
D	FOHS-18696-DA		1			TUB ASY-HTR WTR INLTETT/R	92AC0000050
R	09B-18717-		4			COUPLING ASSY	
R	E9HT-18737-CA		2	D8HZ-2A574-A		SWITCH ASY	
R	FOHT-18737-AA		1			SWITCH ASY-PARKING BRAKE	
R	F1HT-18737-AA		2	F1HZ-2A574-A		SWITCH ASY	
R	E9HT-18737-AA		1	FOHZ-2A574-B		SWITCH ASY-LOW AIR PRESSU	
R	E9AF-18808-AA		2			SPEAKER ASSY - RADIO RECE	
R	E0BF-18813-AA		1			KIT-RADIO ANTENNA	
R	E1AF-18832-AA		1	D5AZ-18832-A		CAPACITOR ASY-VOLT REG	
R	B9FM-18843-A		4	B9MY-13466-A		BULB ASY LAMP	
R	E7HF-18888-DA		1	E7HZ-18888-D		SUPPT-RADO RECVR REAR	
R	F1HT-19710-BC		1	F1HZ-19712-A		COND ASY A/C	
D	F1HS-19835-LA		1			TUB ASY-A/C DEHY TO EVP	92AB0000050
D	F1HS-19835-KA		1	F1HS-19835-KA		TUB ASY-A/C DEHY TO EVP	92AB0000050
D	F1HS-19867-VA		1			HOS ASY-A/C EVP COMPR S/O	92AB0000050
D	F1HS-19867-ZA		1			HOS ASY-A/C EVP COMPR S/O	92AB0000050
R	E7HT-19893-AB		3	E7HZ-19893-B		REG ASY-A/C	
R	F1HT-19972-BA		1	F1HZ-19972-A		TUBE ASY-A/C COMPR TO CON	
R	F1HH-19980-AB		1	F1HZ-19980-A		CONTROL ASY-A/C	
R	F1HT-1A143-AA		2	F1HZ-1A143-A		SHIELD ASSY-RR WHEEL SPLA	
R	F1HT-1A143-CD		1	F1HZ-1A143-C		SHIELD ASSY-RR WHEEL SPLA	
R	F1HT-1A143-BD		1	F1HZ-1A143-B		SHIELD ASSY-RR WHEEL SPLA	
R	E0HS-2A095-AA		3			VALVE ASSY-QUICK REL	
R	D0HA-2A095-A		2			VLV OK REL	
R	E2HT-2A112-AA		1			TUB-BRK RESVR TO UN	
R	E5HT-2A131-BA		3	D9HZ-2A131-B		VLV. ASY. BRK. MOISTURE E	
R	E8HT-2A155-AJA		2			BRK-STAND OFF TUB MNTG	
R	E8HT-2A155-AEA		7			BRKT BRK TUB CLIP	
R	EDD4HA-2A155-CA		1			BRKT-CABLE & TUBE MOUNTIN	
R	F1HT-2A155-ZA		1			BRKT-CABLE & TUBE MOUNTIN	
R	F1HT-2A155-YA		1			BRKT-CABLE & TUBE MOUNTIN	
R	F1HT-2A155-FA		2			BRKT-CABLE & TUBE MOUNTIN	
R	FOHT-2A155-EA		1			BRKT-CABLE & TUBE MOUNTIN	
R	E8HT-2A155-BA		1			BRKT-AIR CMPR DISCH/LN /L	
R	D1HA-2A155-AA		1			BRKT	
R	E8HT-2A155-CA		1			BRKT-AIR CMPR DISCH/LN /R	
R	D0HA-2A155-M		1			BRKT	
R	C5TA-2A155-A		1			BRKT	
R	C3TA-2A155-D		2	C3TA-2A155-D		BRKT	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	C1TT-2A155-D		1			BRKT	
D	C1TT-2A155-A		1			BRKT	92AC0000050
R	E4HT-2A155-AA		1			BRACKET	
R	D5HB-2A205-AB		8	D5HZ-2A205-A		SUPT BRK RESVR TNK	
R	FOHT-2A268-AA		1			BRKT-QUICK REL VLV MTNG	
R	D0HA-2A268-B		1			BRKT QK REL VLV MTNG	
R	E9HT-2A268-AB		1				
R	EDD0HA-2A270-C		1			VLV & TRDL ASY-BRK CONTRL	
R	E2HT-2A271-BA		4	D5HZ-2A271-A		STRP ASY BRK RESVR	
R	C8HA-2A275-B		1			BRACKET	
R	F1HT-2A292-AA		1	F1HZ-2A292-A		CONNECTOR-5/32 X 1/8 PIPE	
R	C6TA-2A384-A		1	C6TZ-2A384-A		COUPLING ASSY BRK TUBE	
R	C6TA-2A384-B		2			COUPL ASY	
R	D6HS-2A384-AA		4	D9HZ-2A384-A		CPL ASY	
R	C6TA-2A435-A		1	C6TZ-2A435-A		VLV. ASY BRK. AIR. PRESS.	
R	E9HT-2A442-AA		2	E9HZ-2A442-A		HOSE ASY-LG.	
R	E6HT-2A449-AA		2	E6HZ-2A449-A		VLV ASY	
R	E5HT-2A550-BA		1	C3TZ-2A550-A		VLV-AIR RESVR SAFETY	
R	E5HT-2A567-BA		3	E6HZ-2A567-D		COCK ASY-BRK RSVR DR	
R	E0HT-2A622-EA		1			VALVE ASSY-PARKING BRAKE	
R	F1HT-2A622-AB		1	F1HZ-2A622-A		VALVE ASSY-PARKING BRAKE	
R	E9HT-2A747-AA		1	FOHZ-2A747-A		VALVE ASY-BRAKE AIR HAND	
R	E5HT-2A783-BA		2	E1HZ-2A783-A		VALVE ASY-P/BRK RESVR	
R	E4HT-2A848-BA		1	E4HZ-2L781-A		KNOB-P/BRK REL	
R	E0HT-2A864-AA		1			NUT-P/BRK CONTR	
R	C1TT-2A876-A		1			GASKET COMPR GOV	
R	FOHT-2A904-AA		1			CONNECTOR 1/4 AB T X 7/16	
R	E5HT-2B170-BA		1	E5HT-2B170-BA		VLV ASY-BRK RESVR CK	
R	D5HA-2B200-AB		1	D5HZ-2951-A		VLV ASY-TRACTR BRK AIR PR	
R	E3HS-2B271-AA		1	E3HS-2B271-AA		DIAL-BRK CONTR VLV	
R	D0HA-2B280-G		1			MANIFOLD BRK AIR SPLY	
R	E3HT-2B407-AA		1	DOHZ-2B407-A		BRKT BRK AIR SPLY MANF	
R	D2HB-2B409-AA		1	D2HZ-2B409-A		SE BRK AIR SPLY MANF MTNG	
D	D5TA-2B422-AD2160		1			TUB ASY 3/8 NYL /RED/	92AD0000020
D	D5TA-2B424-AB2130		1			PLT FAB HOSE	92AD0000020
R	FOHT-2B473-AA		1			TUB ASY 1/8 OD	
R	D0HB-2B475-A		1			REINF ASY-BRK AIR SPLY MA	
R	D5TA-2K119-AA		1	D5TZ-2K119-A		VALVE ASY-DBL CHK	
R	E8HT-3A674-BA		1	E8HZ-3A674-B		PUMP ASY P/S	
R	FOHT-3A719-DA		1			HOSE ASSY-P/S PRESS LINE	
R	F1HT-3B676-AB		1	F1HZ-3B676-A		COUPLING ASSY-STNG GR SHFT	
R	D3TA-3C510-GA		1			BRACKET	
R	E9HT-3C529-HB		1	FOHZ-3C529-A		COLUMN ASY-TILT/TELESCOPI	
R	FOHT-3D677-AA		1			SEAL ASSY-STNG COL OPENIN	
R	E8HT-3E599-BA		1			ELBOW ASSY-P/S PUMP INLET	
R	FOHT-3F527-AA		1			LEVER ASSY-STNG COL LOCK	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	C9HA-3K506-A		1	C9HZ-3K506-A		GASKET-PWR STNG PUMP MTNG	
R	FOHT-3K688-AA		1			ADAPTER-P/S PUMP	
R	FOHT-3L579-AA		4			RETAINER-STEERING COLUMN	
R	F1HT-3N503-EA		1	F1HZ-3504-E		GEAR ASSY - POWER STEERIN	
R	E9HT-4A002-AA		2			SPCR RR AX TOR ARM BRKT	
D	D0HB-4A156-B		1			RLY ASY-RR AX SHIFT CONTR	92AE0000010
R	E9HT-4A375-S281B		1	E9HT-4A375-S281B		AX ASY FWD RR-RD20145-NFN	
R	E9HT-4B430-G281B		1	E9HT-4B430-G281B		AX ASY RR RR-RR20145-NFNN	
R	E9HT-4W040-BA		1	E1HZ-4851-F		YK ASY-U/JT RR RR AX I/P	
R	D0HA-5A076-A		2			SPCR-BDY BLT #1	
D	FOHS-5A112-CD		2			BRACKET	92BB0000010
D	FOHS-5A112-DC		2			BRACKET	92BB0000010
R	FOHT-5A112-DA		1			BRKT-FR TO BDY FRT RH	
R	F1HT-5A112-AB		1	F1HZ-5A113-A		BRKT-ASY-FR TO BDY RH	
R	F1HT-5A113-BB		1	F1HZ-5A113-B		BRKT ASY-FR TO BDY LH	
R	FOHT-5A113-DA		1			BRKT-FR TO BDY FRT LH	
R	C5TA-5A147-A		2			DECAL-FRM WARN	
D	FOHS-5A204-BA		2			BRACKETLRT MFLR SPTR CARD	91A60000070
D	F1HS-5A204-CA		2			BRKT-MFLR SUPTUPPORT-UPPE	91A60000070
D	D7HT-5A204-NC		2	D8HZ-5277-G		BRKT-MFLR SUPT	91A60000070
D	E0HT-5A272-BA		4			CLMP-MFLR OLET PIP	91A60000070
R	E5HT-5A281-AA		1	E5HZ-5A231-A		CLMP ASSY-MFLR INLT PIP	
D	B9TT-5A291-A		4	B9TT-5A291-A		SPG MFLR SUPT CLMP	91A60000070
R	E8HT-5A314-AA		4	E5HZ-5780-A		PIN FRT SPRING BRKT	
R	E8HT-5A314-BA		2	E5HZ-5780-B		PIN-FRT SPRING BRKT	
R	E7HS-5A570-AA		16	E9HZ-5A570-A		WASHER-RR SPRING U-BOLT	
R	E4HT-5A574-AA		4	E4HZ-5A574-A		SPACER REBOUND BOLT	
R	E8HS-5A574-AB		4	E9HZ-5A574-A		SPACER	
R	E7HS-5A664-AA		1	E9HZ-5A664-A		ROD ASY-RR SPRNG LVLNG VL	
R	FOHT-5A687-BA		1			AIR LVLNG VLV ASY	
R	E5HS-5A743-AA		1	FOHZ-5A743-A		VALVE - RR SUSP LEVELING	
D	D0HA-5B286-J		2			CONN-MFLR INLT PIP FLEX	91A60000070
D	E1HT-5B286-BA		1	E1HZ-5B286-B		F240 FLEX PIPE PIP FLEXSH	91A60000070
R	E1HT-5B286-CA		1	E1HZ-5B286-C		CONN-MFLR INLT PIP	
R	FOHT-5B309-DB		1			SPACER-FRT SPRG BRKT (R.H	
R	FOHT-5B310-DB		1			SPCR-FRT SPRG BRKT L.H.	
D	E6HT-5C208-AA		3	E6HT-5C208-AA		CAP ASY-VERT EXH BRIGHT	91A60000070
D	E2HT-5C264-DA		1	E1HZ-5C264-A		CLAMP EXH HT SHLDPTPATEDG	91A60000070
R	F1HT-5D026-AA		1	F2HZ-5D026-A		STEP - FR SLEEPER ACC LWR	
R	F1HT-5D027-AB		1	F1HZ-5D027-A		EXT - FR SLEEPER ACC STEP	
D	E7HS-5D209-KA		1			EXTENSIONINLT PIPT PIPPEP	91A60000070
D	E1HT-5D223-AA		4	E1HZ-5A215-A		STRAP-MFLR SUPT CLMP	91A60000070
D	E7HS-5E207-AA		1			EXTENSIONWELT PIP LHNG (F	91A60000070
D	D7HT-5F230-BA		2	D8HZ-5F230-B		CAP-MFLR SUPT BRKT	91A60000070
R	F1HT-5K307-AA		2	F1HZ-5K307-B		SPCR.FRT.SPRING REAR BRKT	
R	E9HT-5K707-AA		2	E9HZ-5K707-A		C/M-SPRG HNGR	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	FOHT-5K851-AA		2			BRK-RR SUSP AIR SPRNG TO	
R	FOHT-5K852-AA		2			BRKT-RR SUSP AIR SPRNG TO	
R	FOHT-5K862-AB		1			VALVE ASY	
R	E1HT-6A065-AA		2	E1HZ-6A065-B		CAP ENG SUPT	
R	D4HA-6A070-AA		1	D4HZ-6096-B		BRKT-ENG SUPT RR LH	
R	D9HT-6A650-DA		1			FLTR ASY-ENG OIL BYP	
D	C3TA-6A662-F		2			BRACKET	92AB0000050
R	D0HA-6A662-F		1			BRACKET-OIL FLTR HOS SUPT	
R	C3TA-6A662-E		1			BRKT	
R	D3HA-6A662-DA		3			BRKT	
R	F1HT-6A683-BA		1	F1HZ-6A683-C		DEFL ASY-ENG HEAT	
R	D0HA-6B609-D		1			BRKT	
R	D2HA-6B658-AA		1	DOHZ-9A713-A		KIT ENGINE PRIMER CONTROL	
R	E8HT-6C640-BA		1	E8HZ-6C640-B		CONN-ENG CHG AIR COOL DUC	
R	E8HT-6C640-CA		1	E8HZ-6C640-C		CONN-ENG CHG AIR COOL DUC	
R	E8HT-6C640-DA		1	E8HZ-6C640-D		CONN-ENG CHG AIR COOL DUC	
R	E8HT-6C640-JA		1	E8HZ-6C640-G		CONN-ENG CHG AIR COOL DUC	
R	E8HT-6E054-EA		1	F2HT-6E055-A		BRKT ASY-ENG NSE SHLD /RH	
R	F1HT-6E054-AB		1	F1HZ-6E055-C		BRKT ASY - ENG HSE INS SH	
R	E8HT-6E055-DA		1	E8HZ-6E055-AN		BRKT ASY-ENG NSE SHLD /LH	
R	F1HT-6E055-AB		1	F1HZ-6E055-B		BRKT ASY - ENG NSE INS SH	
R	F1HT-6E055-BA		1	F1HZ-6E055-F		BRKT ASY-ENG NSE INS SHLD	
R	F1HT-6K769-LA		1	F1HZ-6K769-D		DUCT-ENG CHG AIR COOL TO	
R	E8HT-6K770-AC		1	E8HZ-6K770-L		DUCT-ENG CHG AIR COOL TO	
R	F1HT-6K770-LA		1	F1HZ-6K770-F		DUCT-ENG CHRGD AIR CLR TO	
R	E9HT-6K786-CB		4	FOHZ-6K786-C		CLAMP-ENG CHG AIR COOL	
R	E9HT-6K786-HA		2	FOHZ-6K786-K		CLAMP-ENG CHG AIR COOL	
R	E9HT-6K786-KA		4	FOHZ-6K786-M		CLAMP-ENG CHG AIR COOL	
R	E8HT-6K854-CB		1	E8HZ-6K854-C		ADPT-CHG AIR COOL TO INTK	
R	F1HT-6M002-AB		1	F1HZ-6775-D		SHLD ASY-ENG NSE UPR R.H.	
R	E8HT-6M003-EC		1	E8HZ-6776-B		SHLD ASY-ENG NSE INS SD-L	
R	F1HT-6M003-BB		1	F1HZ-6776-B		SHLD ASY - ENG NSE UPR L.	
R	TABAJ-77914-B		2	B7T-7034-B		BREA ASY-AUX TRANS CASE	
R	F1HT-7A030-CB		1			TUBE ASY-TRANS OIL COOLER	
R	F1HT-7A030-EA		1			TUBE ASY-TRANS OIL COOLER	
R	F1HT-7A031-CB		1			W380 TUBE ASYNS OIL COOL	
R	D5HS-7A033-CA		1	E1HZ-7A033-D		SUPT TRANS RR	
R	F1HT-7A095-BA		1	F1HZ-7A095-A		COOLER ASSY.-TRANS.OIL	
R	F1HT-7A255-AA		1	F1HZ-7B047-A		BRKT-TRNS TO FR SUP R.H.	
R	C7TA-7A592-A		1	C7TZ-7563-D		PLATE-CL CTR DR	
R	E8HT-7A596-AA		1	E8HZ-7550-A		DISC-1282161-897-P3241000	
R	E8HT-7B118-BA		1	E9HZ-7277-A		BT TRANS GR SH LVR	
R	F1HT-7B143-AA		1	F1HZ-7B143-A		BRACKET TRANS OIL COOLER	
R	E1HT-7B539-AA		1			SPCR-CL REL IDL LVR ADJ	
R	D0HA-7B542-A		1			BMPR ASSY-HOOD %	
R	E7HT-7B552-JA		1	E7HZ-7511-D		LVR ASY CL REL SHFT	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E1HT-7B560-EA		1	E1HZ-7B560-A		ROD ASY-CL VERT CONTROL	
R	D0HA-7B570-C		1			LVR-CL VERT CONTR	
R	D0HS-7B598-A		1			BRKT-CL REL SHFT	
R	F1HT-7C254-AA		1	F1HZ-7B047-B		BRKT-TRANS TO FR SUPT-LH	
R	D7HS-7C345-AA		2	E1HZ-7C345-A		WEDGE TRANS RR SUPT	
R	D3HS-7E434-BA		1	D8HZ-7E434-A		LIMITED TORQUE CL	
R	E2HT-7E491-DA		1	E2HZ-7E491-D		BRKT-TRANS SHFT CONTR MOD	
R	D5HS-7K066-AA		1			REINF TRANS SUPT .38 THK	
R	D5HS-7K066-BA		1			REINF TRANS SUPT .12 THK	
R	D5HS-7K066-CA		2			REINF TRANS SUPT .06 THK	
R	FOHT-7K476-AA		1			BRKT - TRANSMISSION CONTR	
R	E8HT-8A058-BB		1	E8HZ-8A058-A		SUPT-RAD LOWER	
R	F1HT-8A080-AA		1	F1HZ-8A080-A		TANK ASY - RAD SUPPLY	
R	E8HT-8A081-CB		1	E8HZ-8A081-A		BRKT-RAD SUPPLY TNK UPR	
R	E8HT-8A081-DB		1	E8HZ-8A081-C		BRKT AY-RAD SUP TNK	
R	E1HT-8A125-AA		2			REINF RAD GRL CTR SUPT	
R	F1HT-8A125-AB		1	F1HZ-8A125-A		REINF RAD GRL CTR SUPT	
R	E1HT-8A127-FB		2	E1HZ-8A127-A		SPRING RADIATOR LOWER	
R	E8HT-8A326-AA		2	E8HZ-8A326-A		SPACER-RAD MTNG	
R	E8HT-8A365-KA		1	E8HZ-8A365-D		HOSE ASY-RAD SPLY SILIC	
R	F1HT-8A365-ACA		1	F1HZ-8A365-W		HOSE ASY-RADIATOR SUPPLY	
R	E2HT-8A370-AA		2	E2HZ-8A370-A		BOLT-3/4-10 HEX HD SHLD	
R	E8HT-8A397-BA		1	E9HZ-8A397-A		SL-RAD UPR	
R	F1HT-8A397-CA		1	F1HZ-8A397-B		SEAL-RAD UPR	
R	F1HT-8A419-AB		1	F1HZ-8A419-A		SUPT ASY-RAD LWR	
R	E9HT-8A421-AA		4	FOHZ-8A421-A		INSULATOR-RAD SUPT BRKT	
R	D0HA-8A421-C		1			INSULATOR-RAD SUPT BRKT	
R	D0HA-8A421-B		1			INSULATOR-RAD SUPT BRKT	
R	E8HT-8A483-BA		2	F2HZ-8A483-A		SUPT-RAD SUPT	
R	F1HT-8A483-DB		1	F1HZ-8A483-C		SUPPORT-RAD HOSE	
R	F1HT-8A491-AB		1			BRACE-RAD SUPT TO DASH	
R	E4HT-8A491-GA		1	E1HZ-16746-A		BRACE RADIATOR SUPPORT TO	
R	E8HT-8A491-AA		1	E8HZ-16746-A		BRACE-RAD SUPT TO DH RH	
R	E8HT-8A615-EA		1			KIT-BELT DRIVE	
R	D3HA-8A615-JA		1			BELT-KIT 1/2X57.50 P/S	
R	D5HA-8A615-ARA		1			BELT-KIT 1/2X57.50 P/S	
R	F1HT-8A627-JA		1	F1HZ-8A627-J		FAN CLUTCH ASY-BENDIX FD-	
R	E1HT-8A662-AA		1	FOHZ-8A662-A		BOLT FAN ADJUSTING	
R	F1HT-8B231-AA		3	F1HZ-8194-A		RET-RAD GRILLE ORN	
R	F1HT-8B231-BA		3	F1HZ-8194-B		RET-RAD GRILLE ORN	
R	F1HT-8B231-CA		3	F1HZ-8194-C		RET-RAD GRILLE ORN	
R	E1HT-8B236-AA		1	E1HZ-8A339-A		SUPPORT-RAD LWR BRKT RH	
R	F1HT-8B236-AA		1	F1HZ-8A058-A		SUPT RAD LWR BRKT RH	
R	E1HT-8B237-AA		1	E1HZ-8A339-B		SUPPORT RAD LWR BRKT LH	
R	F1HT-8B237-AA		1	F1HZ-8A058-B		SUPT RAD LWR BRKT LH	
R	F1HT-8B375-AA		3	F1HZ-8B375-A		SPACER-RAD GRILLE ORN	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E1HT-8B462-AB		1	E1HZ-8A421-A		INSULATOR-RADIATOR SUPT.	
R	E1HT-8B463-AB		1	E1HZ-8A421-B		INSULATOR-RADIATOR SUPT.	
R	E8HT-8B463-AB		4	E8HZ-8A421-A		INS AY-RAD LWR SUPT	
R	E2HT-8C002-AA		2	E2HZ-8C002-A		WASHER-RADIATOR MTG BOLT	
R	E9HT-8C180-AA		1	FOHZ-8C180-A		SOL ASY-RAD SHTR CONTR O/	
R	E8HT-8K074-AA		1			BRACKET-RAD SHUTT CTRL	
R	F1HT-8K153-FB		1	F1HZ-8K153-H		TUBE ASY-RAD SPLY TNK OLE	
R	E1HT-8K156-BA		1	E1HZ-8A450-A		SPACER-RADIATOR SUPPORT	
R	FOHT-8K157-BA		1			BRKT-RAD TUB SUPT	
R	E8HT-8K612-AA		1	E8HZ-8K612-A		VALVE AY-FAN THERM CONTR	
R	EOHT-8K623-AA		1			PLATE-FAN ADJUSTING	
R	F1HT-8N341-DA		2	F1HZ-8N341-A		SEAL-RAD SIDE	
R	E8HT-8W287-EA		1	E8HZ-8W287-A		CLIP-RADIATOR HOSE	
R	TKBH-99227-A		1			CABLE & TUBE MNTNG BRKT	
R	F1HT-9A017-BA		2	F1HZ-9A017-B		SUPT ASY-FU/TNK	
R	E5HT-9A095-BA		2	E6HZ-9A095-A		LABEL-FUEL-ENGLISH	
R	F1HT-9A105-AB		2	F2HZ-9A105-A		COLLAR-FUEL TANK FILLER P	
D	FOHS-9A151-CA		1			BRKT-ENG PM FLU RESVR MTN	92A30000010
R	E8HT-9A153-AA		2	E8HZ-9A153-A		VLV ASSY-FUEL TNK VNT	
R	C1TF-9A389-A		11	C1TZ-9A389-B		NUT	
R	FOHT-9A710-FA		1			ROD ASY.ACCEL.	
R	E8HT-9A805-FA		1	E8HZ-9A805-F		ROD ASY ACEL B/CRK TO FU/	
R	F1HT-9B038-AA		2			STRIP-INSULATOR (GRILLE-T	
R	E1HT-9B086-AB		2	E1HZ-9B086-A		MEMBER-FU TNK COMP	
R	E1HT-9B105-AA		8	E1HZ-9B105-A		BRKT ASY	
R	F1HT-9B141-AA		2	F1HZ-9B141-A		STEP ASY FUEL TANK FAIR.	
R	F1HT-9B141-BA		2	F1HZ-9B141-B		STEP ASY FUEL TANK FAIR.	
R	E1HT-9B232-AB		16	E1HZ-9B232-A		CLIP-FU TNK STEP RET	
R	E1HT-9B278-DA		1	E1HZ-9B278-D		TUB ASY-OIL PRESS IND -(0	
R	E7HT-9B278-DA		1	E7HZ-9B278-G		TUB ASY OIL PRESS IND 37	
R	D2HA-9B349-AA		1	E6HZ-9189-B		VLV ASSY-ENG PRIMER	
R	F1HT-9B636-AA		1	F1HZ-9B636-A		SCREEN - HOOD SIDE AIR CL	
R	E3HT-9B697-CA		1	E1HZ-9B697-A		DUCT A/CLNR TO INTK MANF	
R	E1HT-9B699-AA		1	E1HZ-9B613-A		HOSE DUCT TO ENG TURBO	
R	F1HT-9C020-BA		1	F1HZ-9C020-B		BRKT-FUEL TANK PNL UPR R.	
R	F1HT-9C021-AB		2	F1HZ-9C021-A		BRKT-FAIRING L/H	
R	F1HT-9C021-BA		1	F1HZ-9C021-B		BRKT-FUEL TANK PNL UPR L.	
R	E5HT-9C681-BA		1	E5HZ-9C681-A		HOSE-A/CLNR TO INTK TUB-U	
R	E1HT-9C681-CA		1	E1HZ-9C681-C		HOSE A/CLNR TO INTK TUBE	
R	F1HT-9C684-CA		1	F1HZ-9B697-F		TUBE ASSY-A/CLNR TO INTK	
R	E9HT-9C871-BA		1	E9HZ-9C888-B		SW & BRKT ASY- SPD CNTRL	
R	E8HT-9C871-AA		1	E8HZ-9C888-A		SWITCH ASY-SPEED CONTROL	
R	FOHT-9C888-AA		1			SW ASSY - SPD CONTROL ACT	
R	C3TA-9D319-A		1			BRKT	
R	F1HT-9D663-AA		1	F1HZ-9D663-A		VLV-CARB A/CLNR DIRT EJCT	
R	E1HT-9D671-AA		1	E1HZ-9626-A		BRKT AIR CLNR TO CWL OTR	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	F1HT-9D671-AB		1	F1HZ-9626-A		BRKT & STRAP ASY-A/CLNR	
R	E1HT-9D672-AA		1	E1HZ-9A627-B		BRKT AIR CLNR TO CWL INR	
R	F1HT-9D672-AA		1	F1HZ-9626-B		BRKT & STRP ASY-A/CLNR IN	
R	D2HA-9D838-DA		1			NOZZLE ASY-ENG PRIM	
R	F1HT-9D838-BA		1	F1HZ-9D838-B		ATOMIZER ASSY	
R	FOHT-9E295-DA		1			WIRE ASY-OIL TEMP INDICAT	
R	E4HT-9E876-AA		1			SUPT & LVR ASY HAND THROT	
R	FOHT-9F291-AA		1			WIRE ASY-OIL PRESSURE IND	
R	FOHT-9F812-AA		1			CNTRL ASY - SPEED CNTRL S	
R	E9HT-9F832-AA		1	E9HZ-9F832-A		SENSOR ASY - ACCEL PEDAL	
R	FOHT-9F834-DA		1			BRACKET-ACCELERATOR PEDAL	
R	E7HT-9J577-BA		1	E7HZ-9775-J		CONTR ASY-ENG STRT ETHER	
R	E7HT-9J577-AA		1	E7HZ-9775-H		CONTR ASY-ENG STRT ETHR I	
R	E1HT-9K622-AA		2	E1HZ-9K622-A		BRKT & STRAP ASY	
R	E2HT-9K652-CA		1	D9HZ-9K652-C		CLAMP ASY	
R	E2HT-9K652-EA		2	E1HZ-9K652-B		CLAMP AIR CLNR PIPE	
R	E2HT-9K652-FA		3	D9HZ-9K652-B		CLAMP ASY	
R	FOHT-9L276-AA		1			CONNECTOR - FUEL TUBE	
R	E8HT-9L437-AA		1	E8HZ-9L437-A		GSKT-INTK MANIF CONN	
R	E4HS-9N622-AA		1	E6HZ-9N622-B		IND ASY ENG A/CLNR RESTC	
R	AA-NOISE-CA		1			CATEGORY / CONFIGURATION	
R	E8HT-10A589-AB		1	E8HZ-10A589-A		W/A-ALT REG	
R	E6HT-10A779-BA		1	E6HZ-10A779-C		BRKT-BATTERY CA	
R	E1HT-10A779-AB		1	E1HZ-10A779-A		BRACKET-BATTERY CABLE	
R	E7HT-10A860-CCP3AY		1	E9HZ-10A885-D		PLT-I/CLUS CONTR MTNG	
R	F1HT-10A894-DBP3AY		1	F1HZ-8004428-G		COVER ASY-INST CLUSTER OP	
R	F1HT-10B686-AA		1	F1HZ-10N698-A		STEP ASY BATT BOX	
R	E7HT-10B843-CA		1	E7HZ-10884-A		SW-WATER TEMP	
R	E9HT-10B853-AA		1	E9HZ-10B853-A		SW ASY-DIFF L/O IND LP	
R	F1HT-10B858-LA		1			W/A DIFFERENTIAL TEMP SEND	
R	E2HT-10B862-AA		3	E2HZ-10B862-A		SENDER ASY-OIL TEMP IND	
R	E7HT-10B864-BA		1	E7HZ-10B864-B		156198 AX TEMP FWD RR	
R	E7HT-10B864-CA		1	E7HZ-10B864-C		156201 AX TEMP RR RRR	
R	FOHT-10B894-AA		2			BEZEL-I/P CLUSTER WARNING	
R	E9HT-10B894-BA		1	E9HZ-10B894-B		BEZEL-I/CLUSTER WRNG LMP	
R	FOHT-10B942-AB		1			W/A-INSTR CLSTR	
R	FOHT-10B987-EB		1			PNL ASY WRNG IND	
R	D7HT-10C343-FA		1	D8HZ-10C343-F		BLOCK-A/C ADJUSTING	
R	D7HT-10C343-EA		1	D8HZ-10C343-E		BLOCK-ALT MTG	
R	E8HT-10C344-EA		1	E8HZ-10C344-A		ROD ALTERNATOR ADJUST	
R	E7HT-10C894-BE		1	E7HZ-10C894-B		BRKT-WRNG IND PNL	
R	E9HT-10C896-FA		1	E9HZ-10C896-E		HSG & JEWEL ASY-INSTR CLU	
R	E9HT-10C896-GA		1	E9HZ-10C896-F		HSG & JEWEL ASY-INSTRU CL	
R	E7HT-10C911-AA		1	E7HZ-10C911-A		INDICATOR ASY-ENG OIL TEM	
R	E7HT-10C924-CA		2	E7HZ-10C924-A		LAMP & WIRE ASY-WRNG IND	
R	FOHT-10D843-DA		2			LENS ASY.WARN.LAMP	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E9HT-10D968-AB		1	E9HZ-10D968-B		SENSOR ASY-LOW COOLANT LE	
R	EOHT-10K852-BA		1			BRKT-BRK AIR PRESS GUAGE	
R	F1HT-10N698-DA		1	F2HZ-10N698-D		STEP ASY BATT BOX	
R	F1HT-10N698-CA		1	F1HZ-10N698-A		STEP ASY BATT BOX	
R	F1HT-10N768-AA		1	F2HZ-10N768-A		BOLT	
R	E9HT-11A596-AA		1	E9HZ-10A885-E		RETAINER ASY - ING. SWITC	
R	D3HB-11A609-AA		1	D3HZ-10852-B		BZL STR P/BTN SW	
R	ED-126915-		1			BRACKET-SEAT STOP	
R	F1HT-12A581-HA		1	F1HZ-12A581-H		W/A ENGINE CONTROL SENSOR	
R	FOHT-12A690-CB		1			W/A ENG. CONTROL SENSOR E	
R	FOHT-12A690-AB		1			W/A ENG. CONTROL SENSOR E	
R	ED-139851-		1			BRKT	
R	D2AB-13A024-AA		1			SW ASY HD/LP DIM	
R	D7OB-13A093-AA		8			SCREW & NUT ASY-HEAD LAMP	
R	FOHT-13A138-AA		2			CVR-HD/LMP	
R	E9HT-13A344-AB		1	FOHZ-13K025-A		BRACKET TURN SIGNAL SWITC	
R	F1HT-13A360-AA		2	F1HZ-13A360-A		HOUSING TURN SIGNAL IND L	
R	F1HT-13A372-AA		2	F1HZ-13A372-A		SEAL TURN SIG IND LMP MNT	
R	E9HT-13A411-AA		1	E9HZ-13A411-A		W/A-STOP LAMP SWITCH	
R	E9HT-13A565-AA		2	E9HZ-13380-A		REFLECTOR ASY-RR	
D	D5HS-13A581-AA		1			BRKT	92AD0000020
R	E3HT-13A631-AA		1	D2TZ-13480-A		SW ASY-STP LMP	
R	E3HT-13A772-AA		1	E3HZ-13713-A		SW & BT ASY CURT LP	
R	E7HT-13A803-EA		1	E7HZ-13832-A		HORN & SUPT ASY	
R	E7HT-13A803-FA		1	E7HZ-13832-B		HORN & SUPT ASY	
R	E7HT-13A805-AA		1	E6HZ-13A805-A		BUTTON ASY-HORN BLOW	
R	E1HT-13A826-AA		1	E1HZ-13A826-A		BRKT-AIR HORN	
R	FOHT-13B302-AB		1			SWITCH ASY-TURN & EMERG S	
R	D0HB-13B711-A		1			WIR ASY CURT LAMP	
R	E7HT-13B789-AA		1			HOUSING ASY-I/PNL LAMP	
R	E9HT-13C082-AA		12	E9HZ-13C082-A		RET-HD LP OPENING MLDG.	
R	E7HT-13C780-AA		1	E7HZ-13C780-A		SW ASY-DOME & TRLR LPS CO	
R	E3HS-13K713-AA		1	E4HZ-13K713-A		KNOB ASY-I/CLSTR LAMP RHE	
R	D7HT-13K832-AA		1	D8HZ-13K832-A		LANYARD	
R	F1HT-13N232-AE		1	F1HZ-13N232-A		BRKT - LAMP MOUNTING R/H	
R	F1HT-13N232-AC		1			BRKT - LAMP MOUNTING R/H	
R	F1HT-13N233-AE		1	F1HZ-13N232-D		BRKT - LAMP MOUNTING L/H	
R	F1HT-13N233-AC		1			BRKT - LAMP MOUNTING L/H	
R	D7HT-13N492-AA		2	D8HZ-13N492-A		CVR RR LP HSG ACC	
R	E7HT-14A066-AA		1	E7HZ-14A066-A		BRKT-CIR BRKR MTG	
R	F1HT-14A067-FB		1	F1HZ-14A067-A		PANEL ASY-FUSE JUNCTION	
R	E8HT-14A099-AB		2	FOHZ-14A099-C		SHLD WIR	
R	E7HT-14A257-ACP3AY		1	E7HZ-14A257-A		CVR ASY-RELAY & CIR BRKR	
R	E8HT-14A284-CA		1	E8HZ-14A284-C		BRKT WIRE CLIP	
R	E8HT-14A284-AD		1	E8HZ-14A284-A		BRKT-TUBE SUPT	
R	F1HT-14A298-AA		2	F1HZ-14A298-A		BRACKET - JUNCTION BLOCK	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
D	E9HT-14A298-AC		1			BRKT - JCT BLK	92AE0000010
R	FOHT-14A318-AA		1			W/A-ACCESSORY FEED	
R	E9HT-14A341-GA		1	E9HZ-14A341-G		OUTLET & W/A-TRLR WIRE	
R	E9HT-14A341-HA		1	E9HZ-14A341-H		OUTLET & W/A - TRAILER WI	
D	FOHS-14A341-CA		1			OLET & WIR ASY-TRLR WIRIR	92AD0000020
R	FOHT-14A382-BC		2			W/A WARNING INDICATOR EXT	
R	E8HT-14A382-BD		1	E8HZ-14A382-B		W/A-INSTR CLSTR	
R	E8HT-14A398-BA		1			DECAL-JCT BLK TRMNL IDENT	
R	E8HT-14A398-DA		1			DECAL-JCT BLK TRMNL IDENT	
D	E7HS-14A398-BA		1			WIRE	92AE0000010
R	D0HB-14A398-D		1			DECAL-JCT BLK TRMNL	
R	E8HT-14A398-EB		1			DECAL-JCT BLK TRMNL IDENT	
R	E8HT-14A398-JA		1			DECAL-JCT BLK TRMNL IDENT	
D	FOHT-14A405-BAP3BP		2			CVR ASY-JCT BLK	92AE0000010
D	E7HS-14A411-AA		1			WIRE ASSY	92AE0000010
R	F1HT-14B194-AA		1	F1HZ-14677-A		RELAY & BRKT ASSY MULTI F	
R	FOHT-14K067-BA		1			W/A-WRNG LP FD JMPR	
R	E8HT-14K067-BA		1	E8HZ-14K067-B		W/A-WARNING LAMP FEED JMP	
R	E9HT-14K073-JA		1	E9HZ-14K073-J		W/A-TEMP SENDER EXTENSION	
R	E8HT-15A404-AD		1	E8HZ-15A404-A		WIRING ASY-MRKR LP TO SWI	
R	C9TB-15A543-A		1			GASKET BK UP LP SW	
R	F1HT-15B465-AB		1	F1HZ-15B465-A		W/A - ORNAMENT LAMP FEED	
R	F1HT-15K201-AC		2			FOG LAMP ASSY	
R	F1HT-16A023-BB		1	F1HZ-16A023-B		BRACE - FRONT FENDER UPPE	
R	F1HT-16A024-BA		1	F1HZ-16A024-B		BRA - FRT FNDR UPR LH	
R	E1HT-16A262-AD		1	E1HZ-16B568-A		SHLD FRT WHL SPLS (RH)	
R	E2HT-16A262-BA		2	E2HZ-16A266-A		GUARD FRT WHL SPLASH	
R	E1HT-16A263-AC		1	E1HZ-16B569-A		SHLD FRT WHL SPLS (LH)	
R	F1HT-16A266-AB		1			SHLD ASY-FRT WHL SPL RH	
R	F1HT-16A267-AB		1			SHLD ASY FRT WHL SPL LH	
R	E3HT-16A322-AA		2			REINF-FRT WHL SPLS SHLD	
R	D0HB-16A584-A		2			BRKT ENG RR SPLS SHLD	
R	F1HT-16A586-BA		2	F1HZ-16A586-B		SHLD-FRT WHL SPLS RR	
R	F1HT-16A636-AA		2	F1HZ-90020A74-A		ORN ASY HOOD SD	
R	EDF1HT-16B568-AA		1			SHIELD	
R	EDF1HT-16B569-AA		1			SHIELD	
R	F1HT-16B668-AA		1	F1HZ-16B668-A		PNL - HOOD SIDE AIR CLEAN	
R	FOHT-16B702-AA		1			BRKT HD STAB RAD SUPT LH	
R	F1HT-16B702-BA		2			BRKT HD STAB SUPT (RH)	
R	E2HT-16B702-BA		1	E2HZ-16B702-A		BRKT HD STAB SUPT (RH)	
R	F1HT-16B702-AA		1			BRKT ASSY-HOOD STAB(RAD-T	
R	E8HT-16B770-AB		2	E8HZ-16738-F		INSUL HOOD SOUND FRNT	
R	F1HT-16B770-AB		1	F1HZ-16738-B		INSUL HOOD SOUND FRNT	
R	E9HT-16B898-CA		2	FOHZ-16B898-A		CABLE ASY-HOOD CHECK	
R	F1HT-16B898-AA		2	F1HZ-16B898-A		CABLE ASY-HOD CHK	
R	D0HB-16B920-A		4			RET-HOOD CHECK CABLE	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E7HT-16C569-AA		2	E7HZ-16C569-A		BRKT FRT WHL SPLH GD	
R	E1HT-16C658-CA		1	E1HZ-16C658-A		STAB ASSY-HOOD	
R	F1HT-16C658-DB		2	F1HZ-16C658-D		STAB ASY-HOOD UPR (SIDE R	
R	F1HT-16C658-CA		2	F1HT-16C658-CA		STAB ASY-HOOD(SIDE ROLLER	
R	F1HT-16C658-AA		1	F1HZ-16C658-C		STAB ASY-HOOD(CENTER)	
R	E2HT-16C658-AA		1	E2HZ-16C658-A		STAB ASY HD (RH)	
R	E2HT-16C659-AA		1	E2HZ-16C659-A		STAB ASY HD (LH)	
R	D0HB-16C702-B		1			SEAL-HOOD STAB BRKT	
R	E3HT-16C704-AA		1	DOHZ-16C704-A		BRACE HOOD STAB BRKT	
R	E5HT-16C728-AA		2	E5HZ-16C728-A		SPG-HOOD CHECK CABLE	
R	E1HT-16C748-AA		2	E1HZ-16C748-A		RET-HOD ASST	
R	E1HT-16C842-AC		2	E1HZ-16C842-A		STAB ASY-HOD ON HOD LWR (
R	E1HT-16C844-AC		1	E1HZ-16C844-A		STAB ASY-HOD ON BDY LWR (
R	E1HT-16C845-BB		1	E1HZ-16C845-B		STAB ASY-HOD ON BDY LWR (
R	E2HT-16C846-AA		1	E1HZ-16C846-A		PLT-HOD STAB LWR ON HOD M	
R	FOHT-16C847-AA		1			PLT-HOD STAB LWR ON BDY H	
R	E2HT-16C848-AA		1	E1HZ-16C848-A		PLT ASY-HOD STAB LWR ON B	
R	E2HT-16C849-AA		1	E1HZ-16C849-A		PLT ASY-HOD STAB LWR ON B	
R	F1HT-16C850-AA		1	F1HZ-16C850-A		BRA-HOD STAB LWR ON BDY M	
R	E1HT-16C850-AA		1	E1HZ-16C850-A		BRA-HOD STAB LWR ON BDY M	
R	F1HT-16C851-AA		1	F1HZ-16C851-A		BRA-HOD STAB LWR ON BDY M	
R	E1HT-16C851-AA		1	E1HZ-16C851-A		BRA-HOD STAB LWR ON BDY M	
R	E5HT-16C852-AA		1	E1HZ-16C852-A		PLATE ASY-HOD FRT ORN MED	
R	F1HT-16F570-AA		1	F1HZ-16F570-A		SHLD-FRT FNDR OPG SPL FRT	
R	F1HT-16F571-AA		1	F1HZ-16F571-A		SHLD-FRT FNDR OPG SPL FRT	
R	F1HT-16G554-AA		1	F1HZ-16G554-A		SHLD-FRT FNDR OPG SPL RR	
R	F1HT-16G555-AA		1	F1HZ-16G555-A		SHLD-FRT FNDR OPG SPL RR	
R	FOHT-16N781-AA		2			CATCH HOOD LOCK	
R	ED-171370-		1			DEFL ASY FRT BMPR STD CTR	
R	F1HT-17A720-BB		1			SUPPORT ASY A/C PLENUM CH	
R	D0HB-17A732-D		1			SUPT ASY R/V O/S MIR UPR	
R	D0HB-17A734-D		1			BRACE R/V O/S MIR SUPT RH	
R	D0HB-17A736-D		1			SUPT ASY R/V O/S MIR LWR	
R	FOHT-17B384-AA		1			SENSOR & RETAINER ASY-TAC	
R	D0HB-17B609-A		1			RET W/SHLD WSHR PMP	
R	E8HS-17B717-TA		1			MIR & GD ASY-R/V O/S LS A	
R	FOHT-17B717-DA		1			MIR & GD ASY-R/V O/S LS A	
R	E9HT-17B719-AB		2	E9HZ-17B719-A		WIR ASY-R/V O/S MIR LP FD	
R	E8HT-17B783-AA		2	E8HZ-17B783-A		SPACER-FRT BUMPER	
R	D0HB-17C708-D		1			BRA R/V O/S MIR SUPT	
R	FOHT-17C732-BA		1			MIR & GUARD ASY RR VIEW *	
R	D0HA-17C797-C		2			PLATE-FRT. TOW HOOK BLT.	
R	D3HB-17K605-AA		1			HOSE ASY W/SHLD WSHR	
R	FOHT-18A035-AA		4			BRACKET-SHK ABS MNTG	
R	C1TT-18A065-A		4	C1TT-18A065-A		WASHER SHK ABS INS-LWR	
R	F1HT-18A160-AC		2	F1HZ-18A160-A		ABSORBER ASY - CAB SUSP S	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	F1HT-18A160-BC		2	F1HZ-18A160-B		ABSORBER ASY - CAB SUSP S	
R	F1HH-18A277-BC		1	F1HZ-18A277-B		COVER-HEATER BLOWER HOUSI	
R	D9AF-18A927-BA		1	D9AZ-18A927-A		CAP - RADIO ANTENNA BASE	
R	E8HF-18A984-AA		1			BASE & CABLE ASY-RADIO AN	
R	E3HS-18B828-AA		1	E4HZ-18B828-A		COVER	
R	E7HT-18B971-BA		1	E7HZ-18B971-B		W/A-JMPR-RADIO RECV WIRE	
R	E7HT-18C332-BA		1	E7HZ-18C332-B		CVR-HTR PLNM CHMBR OPNG	
R	F1HH-18C424-AC		1			HEATER & A/COND ASSY-INTE	
R	F1HH-18C433-AC		1	F1HZ-18C433-A		DUCT ASY-HTR OUTLET TO FL	
R	F1HH-18D306-AB		1	F1HZ-18518-A		CAB ASY-HTR TEMP REG CONT	
R	E7HT-18K490-AA		1	E7HZ-18K490-A		HOUSING ASY-HTR REG LH	
R	E8HF-18K834-AA		1	E7HZ-18K834-A		BRACKET-RADIO HSG	
R	E8HF-19A015-AAP3AR		1	E7HZ-18842-A		HSG-RADIO CONTROL	
R	E8HF-19A028-AA		1	E7HZ-18888-C		BRACKET ASSY-RADIO RECEIV	
D	FOHS-19A041-AA		1			WIR ASY-RADO SPKR	92AE0000010
R	FOHT-19A041-AA		1			W/A - RADIO SPEAKER	
R	F1HT-19A268-AA		1			MAN-SAF STD CERT	
R	E7HT-19A321-NA		1			MAN-OWNER VEH OPER & INFO	
R	E7HT-19A321-FA		1			MAN-OWNR VEH OPER & INFO	
R	F1HT-19A340-AA		1	F2HZ-19A340-A		KIT-CHASSIS DECK PLT	
R	FOHT-19A347-AA		1			DECAL-FEDERAL NOISE COMPL	
R	F1HT-19A364-HA		1			TEMPL-PNT SRP (CAB) RH	
R	F1HT-19A364-EA		1			TEMPL-PNT SRP (UPR HOOD)	
R	F1HT-19A364-FA		1			TEMPL-PNT SRP (FENDER) RH	
R	F1HT-19A364-GA		1			TEMPL-PNT SRP (COWL LWR)R	
R	F1HT-19A365-HA		1			TEMPL-PNT SRP (CAB) LH	
R	F1HT-19A365-EA		1			TEMPL-PNT SRP (UPR HOOD)	
R	F1HT-19A365-GA		1			TEMPL-PNT SRP (COWL LWR)	
R	F1HT-19A365-FA		1			TEMPL-PNT SRP (FENDER) LH	
R	E7AJ-19A406-AA		1			CRD WRNT WONR CRD CARR	
R	F1HH-19A688-AA		1			TAG-A/C CONDENSER REFRIG	
R	E0SH-19A688-AA		1			TAG-A/C REFRIG CHG	
R	F1HH-19A705-AA		1	F1HZ-19A705-A		TUBE ASY A/C EVAPORATOR O	
R	F1HT-19A885-AA		1	FOHZ-19A885-A		W/A- A/C THERMOSTAT TO CL	
R	F0SF-19B132-AA		1			FOREIGN STOCK RECEIVED	
R	FOHT-19B573-BB		1			W/A-A/C CLUTCH COIL LEAD	
R	E7HT-19C696-AC		2	E7HZ-19893-A		REG ASY-A/C INSTR/PNL LH	
D	E9HS-19C789-AA		1			BRACKETC TUBE SUPT SUPTSY	92AC0000050
R	F1HH-19D606-AB		1	F1HZ-19D606-A		BRACKET ASY-A/C ACUMM	
R	E3TH-19D607-BB		2	E3TZ-19D607-D		BRACKET ASSY	
R	E8HT-19D624-DA		1	E4HZ-19D624-D		BRKT-A/CONDT COMPR MTG	
R	F1HT-19D629-AA		1	F1HZ-19703-B		CMPR & CL ASY-A/C	
R	E8HT-19D775-CB		1	E8HZ-2889-A		PLATE-A/CONDT COMPR RR	
R	FOHT-19D887-FA		1			W/A - AIR CONDITIONER JUM	
R	F1HT-19E568-AA		1	F1HZ-19E568-A		MANIFOLD ASY-A/C DISCHARG	
R	E8HT-19E633-BA		1	E8HZ-19E633-A		PLATE ASY-A/CONDT COMPR F	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	F1HH-19E647-CA		1	F1HZ-19C836-C		ACCUM & SWITCH ASY-A/C	
R	E3HT-19F533-BA		2	FOHZ-17682-M		MIR ASY-DMSH	
R	D2HA-19N570-AA		1	D2HZ-6001454-A		DUCT ASY-VENT AIR-RH	
R	F1HT-278D82-AC		6	F1HZ-90278D82-A		BRKT - BDY SD PNL RR	
R	F1HT-278D88-AC		1	F1HZ-90278D88-A		REINF - BDY SD PNL FRT UP	
R	F1HT-278D88-AA		1	F1HZ-90278D88-A		REINF - BDY SD PNL FRT UP	
R	F1HT-278D89-AA		1	F1HZ-90278D89-A		REINF - BDY SD PNL FRT UP	
R	F1HT-278D89-AC		1	F1HZ-90278D89-A		REINF - BDY SD PNL FRT UP	
R	F1HT-278D90-AA		1	F1HZ-90278D90-A		REINF - BDY SD PNL FRT LO	
R	F1HT-278D90-AC		1	F1HZ-90278D90-A		REINF - BDY SD PNL FRT LO	
R	F1HT-278D91-AA		1	F1HZ-90278D91-A		REINF - BDY SD PNL FRT LO	
R	F1HT-278D91-AC		1	F1HZ-90278D91-A		REINF - BDY SD PNL FRT LO	
R	F1HT-278D92-ED		1	F1HZ-90278D92-E		REINF-BDY SD PNL RR UPPER	
R	F1HT-278D93-ED		1	F1HZ-90278D93-E		REINF - BDY SD PNL RR UPP	
R	F1HT-278D94-RA		1	F1HZ-90278D94-G		REINF - BDY SD PNL RR LOW	
R	F1HT-278D94-ED		1	F1HZ-90278D94-D		REINF - BDY SD PNL RR LOW	
R	F1HT-278D95-ED		1	F1HZ-90278D95-D		REINF - BDY SD PNL RR LOW	
R	ESBM-50J107-AAP6DP		2			ENAMEL, ACRYLIC, NAD-EXTE	
R	ESBM-50J107-AAEAB2		2			ENAMEL, ACRYLIC, NAD-EXTE	
R	REAR-BRAKES-R666G		4			BRAKE PLANNING	
R	FRONT-BRAKES-R666G		2			BRAKE PLANNING	
R	LTL-SERIES-3406		1			PLANNING	
R	TOTAL-SERIES-3406		1			PLANNING	
R	TOTAL-SERIES-TAND		1			PLANNING	
R	TOTAL-SERIES-HN72		1			PLANNING PART	
R	TOTAL-SERIES-9000		1			PLANNING	
R	LTLS90-SERIES-DIESEL		1			PLANNINGPART	
R	D3TA-1002105-AA		1	D2TZ-1002105-A		VENT ASY-COWL SIDE-LH	
R	D5TB-1021850-AA		2	D5TZ-1021850-A		KNOB DR LAT CONT ROD	
R	D7TB-1042436-AA		1	D7TZ-1042436-B		CVR BK WDO O/S LWR MLDG J	
R	FOHT-3322050-AA		1			LOCKSET	
R	E4HT-5000130-AA		2	E4HZ-5000130-A		SPCR-#1 BDY BLT	
R	C6AB-6221982-C		2	C5AZ-6222008-A		STRKR ASSY DR LK	
R	D0DB-6222021-A		2			RET-DR LK STRKR ANC PLT	
R	D32B-6222023-AA		2	C5AZ-6222023-A		RET DR LK CYL	
R	D3DB-6222024-AA		2	D3DZ-6222024-A		PLT DR LK STRKR ANC	
R	E9HT-6501631-AA		1			PLT-VEH IDENT	
D	REQ-7800000-		1			MAINT PARTFRT ST BACKBNJN	92AD0000020
R	D0HA-8000149-B		2			INSL ASY-BDY BLT	
R	FOHT-8001552-AA		1			REINF.BRK.PDL.SUPT.DASH P	
R	D0HB-8001691-A		5			RET DH SND INS	
R	D0HB-8002000-A		1			REINF CWL TOP PNL	
R	F1HT-8002012-AB		1	FOHZ-8002012-A		PNL ASY-CWL TOP OTR	
R	F1HT-8002018-AA		1	E7HZ-8002018-A		PNL ASY-CWL TOP INR	
R	E8HT-8002038-AA		1	E8HZ-8002038-A		PNL ASY CWL SD INR	
R	E8HT-8002039-AA		1	E8HZ-8002039-A		PNL ASY CWL SD INR	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E7HT-8002062-AB		1	DOHZ-80022A44-A		EXT-CWL SD PNL RH	
R	D0HB-8002096-C		1			EXT-CWL SD VENT AIR PNL-R	
R	D0HB-8002097-B		1			EXT-CWL SD VENT AIR PNL-L	
R	D0HB-8002228-C		1			GRL CWL TOP PNL	
R	EDE7HT-8002300-AA		1	E1HZ-8002300-A		PNL ASY CWL SIDE VENT AIR	
R	EDE7HT-8002301-AA		1	E1HZ-8002301-A		PNL ASY CWL SIDE VENT AIR	
R	F1HT-8002388-AAJAAF		1	F1HZ-8002344-AAJ		CARPET ASY-COWL SD RH	
R	F1HT-8002389-AAJAAF		1	F1HZ-8002345-AAJ		CARPET-COWL SD LH	
R	E7HT-8002448-AA		2			PLT CWL SD PNL ACC HOLE C	
R	D0HB-8002508-B		1			PLR FRT BODY UPR INR	
R	D0HB-8002509-B		1			PLR FRT BDY UPR INR	
R	FOHT-8002536-AA		1			PLR ASY FRT BDY UPR OTR R	
R	FOHT-8002537-AA		1			PLR ASY FRT BDY UPR OTR L	
R	D0HB-8002638-A		2			PLT FRT BDY PLR HGE ANC R	
R	D0HB-8002639-A		2			PLT FRT BDY PLR HGE ANC L	
R	D1HB-8002824-AA		1	DOHZ-16740-A		SE CWL TOP PNL TO HOOD	
R	D4HB-8003100-BA		1	D3HZ-8003100-B		GL ASY W/SHLD-TNTD	
R	E2HT-8003110-AA		1	E2HZ-8003110-A		W/S W/SHLD	
R	E4HT-8003410-AA		1			PNL W/SHLD HDR INR	
R	E1HT-8004100-BAP3A1		1	E4HZ-8004104-C5P		VIS ASY I/S RH	
R	E1HT-8004101-BAP3A1		1	E4HZ-8004105-C5P		VIS ASY-I/S LH	
R	E9HT-8004338-KBP6DA		1	E9HZ-8004338-D		PNL-I/PNL FNSH RH	
R	F1HT-8004339-CAP6DA		1	F1HZ-8004339-B		PNL-I/PNL FNSH LH	
R	E7HT-8004810-ABP3AY		1	E8HZ-8004810-A		RECPT ASY-I/PNL ASH	
R	F1HT-8010110-AA		2	FOHZ-8010110-A		MEMBER ASSY - FLOOR SIDE	
R	FOHT-8010120-AB		1			MBR FLR SD OTR RH	
R	FOHT-8010121-AB		1			MBR FLR SD OTR LH	
R	D5HB-8010254-AA		1	D5HZ-8010254-A		EXT FLR SD MBR FRT RH	
R	D5HB-8010255-AA		1	D5HZ-8010255-A		EXT FLR SD MBR FRT LH	
R	E7HT-8010318-BAP3AC		1			PNL ASY ENG CVR	
R	E9HT-8010318-AAP3AC		1	E7HZ-8010318-A		PNL ASY ENG CVR	
R	FOHT-8010502-AA		2			EXT-FLR SD INR MBR RR	
R	E7HT-8010550-ABP3BP		1	E7HZ-8010550-A4P		CARPET-ENG CVR	
R	FOHT-8010550-AAP3BP		1			CARPET-ENG CVR	
R	FOHT-8010624-AA		1			MBR FLR PAN CR CTR	
R	D5HB-8010684-AA		1	DOHZ-8010684-A		MBR FLR PAN CR FRT	
R	E2HT-8010685-AA		1	DOHZ-8010685-A		MBR FLR PAN FRT CS LH	
R	F1HT-8011112-BA		1			INSULATOR-FRT FLOOR PAN H	
R	F1HT-8013000-DAP3BP		1	F1HZ-8013000-DAP		CARPET ASY.FLR.FRT.	
R	FOHT-8013204-AA		1			SPCR DR SCF PLT R.H.	
R	FOHT-8013205-AA		1			SPCR DR SCF PLT L.H.	
R	E8HT-8013208-BA		1	E8HZ-8013208-B		PLATE-DR SCUFF RH	
R	E8HT-8013209-BA		1	E8HZ-8013209-B		PLT-DR SCUFF LH	
R	E7HT-8020100-AAP3AR		2	E7HZ-8020100-A		A10634113, E-T- PER DBROW	
R	F1HT-8020124-BA		1			DOOR ASSY RH	
R	F1HT-8020125-BA		1			DOOR ASSY-LH	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E7HT-8020168-AA		1	DOHZ-8020168-A		REINF-DR FRT FRAME UPR	
R	E7HT-8020169-AA		1	DOHZ-8020169-A		REINF-DR FRT FRAME UPR	
R	D0HB-8020174-B		2			REINF DR RR FRM AT LAT	
R	FOHT-8020176-AA		1			REINF.ASY.DR.RR.FR.RH.	
R	FOHT-8020177-AA		1			REINF.ASY.DR.RR.FR.L.H.	
R	D0HB-8020196-A		1			REINF-DR FRT FR LWR	
R	D0HB-8020197-A		1			REINF-DR FRT FR LWR	
R	D0HB-8020366-A		2			WEDGE-DR TOP	
R	D0HB-8020368-A		2			PLT-DR TOP WEDGE STRKR	
R	D0HB-8020378-A		2			WEDGE ASY-DR BOTTOM	
R	D0HB-8020390-A		2			PLT-DR BOT WEDGE STRIKER	
R	E2HT-8020782-AA		2	E3HZ-8020530-A		W/STRP DR OPNG	
R	D0HB-8021132-A		2			GSKT DR I/S PNL ACC CVR	
R	E2HT-8021402-DA		1			WDO ASY-DR VNT RH	
R	E2HT-8021403-DA		1			WDO ASY-DR VNT LH	
R	E4HT-8021410-BA		2	DOHZ-8021410-B		GLASS TINTED COMPLETE	
R	D0HB-8021452-A		1			W/STRIP ASY DR WDO GL RH	
R	D0HB-8021453-A		1			W/STRIP ASY DR WDO GL LH	
R	D0HB-8021458-B		1			CHAN ASY DR WDO GL	
R	D0HB-8021459-B		1			CHAN ASY RR WDO GL	
R	EDD0HB-8021548-A		2			RUN ASY-DR GL	
R	E5HT-8021660-AA		2	DOHZ-8021546-A		RUN DR VT WDO DIV BAR GL	
R	E9HT-8021812-AA		1	F1HZ-8021812-A		LAT ASY DR RH	
R	E9HT-8021813-AA		1	F1HZ-8021813-A		LAT ASY DR LH	
R	E1HT-8021818-AA		1	E1HZ-8021818-A		REMOTE CTRL ASSY DR LK RH	
R	E1HT-8021819-AA		1	E1HZ-8021819-A		REMOTE CTRL ASSY DR LK LH	
R	D0HB-8021852-A		1			ROD DR LAT PUSH BUTTON RH	
R	D0HB-8021853-A		1			ROD DR LAT PUSH BUTTON LH	
R	D0HB-8021914-A		2			LINK ASY-DR LAT R/CONTR	
R	E9HT-8022134-AA		2	F1HZ-8022134-A		ROD DR LATCH CONTR TO CYL	
R	F1HT-8022400-AA		1	F1HZ-8022404-A		HNDL ASSY DR-O/S R.H.	
R	F1HT-8022401-AA		1	F1HZ-8022405-A		HNDL ASSY-DR O/S L.H.	
R	E1HT-8022614-AA		2	E1HZ-8022600-A		HANDLE DR I/S	
R	D2HB-8022800-AA		1	DOHZ-8022800-A		HGE ASY DR UPR	
R	D2HB-8022801-AA		1	DOHZ-8022801-A		HGE ASY DR UPR	
R	D2HB-8022810-AA		1	DOHZ-8022810-A		HGE ASY DR LWR	
R	D2HB-8022811-AA		1	DOHZ-8022811-A		HGE ASY DR LWR LH	
R	E0HT-8023200-AA		1			2REGULATOR ASSY-DR WDO	
R	E0HT-8023201-AA		1			2REGULATOR ASSY-DR WDO	
R	D0HB-8023227-A		2			SPCR DR WDO REG HNDL	
R	D0HB-8023230-A		2			BRKT ASY DR WDO REG EQUIL	
R	D0HB-8023296-A		2			BRKT DR WDO GL CHAN RR	
R	EDD2HB-8023342-AB		2			HDL ASY DR WDO REG	
R	D0HB-8023370-A		4			PLT DR WDO REG HNDL	
R	D0HB-8023510-A		2			BRKT-DR CK ARM ON BDY	
R	E5HT-8023552-AA		2	DOHZ-8023552-A		CHECK ASY-DR	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	E8HT-8023718-AA		1	E8HZ-8020104-A		PCKT ASY-DR RH	
R	E8HT-8023719-AA		1	E8HZ-8020105-A		PCKT ASY-DR LH	
R	E7HT-8023866-AAP3BP		2	E7HZ-8020126-B4P		CVR-DR PCKT OTR	
R	E8HT-8023942-DAP6CJ		1	E8HZ-8023942-DSP		PNL ASY-DR TR /HI-LVL/ RH	
R	E8HT-8023943-DAP6CJ		1	E8HZ-8023943-DSP		PNL ASY-DR TR /HI-LVL/ LH	
R	E1HT-8024116-AB		2	E1HZ-8024116-A		BRKT DOOR ARM REST	
R	F1HT-8025622-AA		2	E7HZ-90020A74-A		PLATE BDY SD NAME	
R	E8HT-8026690-AA		2	E8HZ-8026690-A		HNDL DR I/S PL	
R	D0HB-8032218-D		1			RL BDY SD LWR RH	
R	D0HB-8032219-D		1			RL BDY SD LWR LH	
R	F0HT-8040304-AA		1			PNL BK	
R	F0HT-8040484-AA		1			PANEL BACK INNER	
R	D5HB-8040492-AA		1	DOHZ-8040492-A		PNL BK INR LWR RH	
R	D5HB-8040493-AA		1	DOHZ-8040493-A		PNL BK INR LWR LH	
R	D4HB-8042006-BA		1	D3HZ-8042006-B		GL BK WDO-TNTD	
R	F0HT-8042084-AA		1			W/STRIP BACK WDO	
R	E8HT-8050202-BC		1			PNL-RF	
R	E1HT-8050290-AA		1	DOHZ-8050290-A		E-T- PER D.BROWN	
R	E1HT-8050291-AA		1	DOHZ-8050291-A		E-T- PER D.BROWN	
R	E4HT-8051700-AB		1	E4HZ-8051700-A		MLDG RF DRIP SD RH	
R	E4HT-8051701-AB		1	E4HZ-8051701-A		MLDG RF DRIP SD LH	
R	E4HT-8051704-AB		1	E4HZ-8051704-A		MLDG RF O/S RR	
R	E8HT-8051952-AA		1			SPACER - RF TR PNL	
R	E8HT-8051968-ABP3A1		1	E8HZ-8051968-A5P		PNL ASY-RF TR	
R	F0HT-8052052-ABP3A1		1			PNL ASY-ROOF TRIM REAR	
R	E8HT-8052118-ABP3AY		2			RET RF TR PNL FRT	
R	E2HT-8052124-BA		8	E1HZ-8052124-B		RET ASY-RF TR PNL	
R	E8HT-8052188-AAP3AY		1			RET-RF TR RR	
R	D1E8HT-8052189-AA		1	E8HZ-8052184-A		SUPT-RF HD/LNG RR	
R	E0HT-8054310-AA		2			ABS RF PNL SND	
R	D3HB-8054322-BA		2			ABS RF PNL CTR SND	
R	E5HT-8054336-AA		2	F1HZ-8054310-A		ABS RF REINF SD	
R	F1HT-9001610-AB		1	F1HZ-9001610-A		PNL ASY-DH (DOGHOUSE W/AI	
R	E2HT-9003144-AA		1	E2HZ-8003144-A		MLDG W/SHLD O/S	
R	F1HT-9004826-AA		1	E8HZ-8004826-A		RET ASY-I/P ASH RECPT	
R	E1HT-9010128-AH		1	E1HZ-9010128-A		PNL ASY-BDY RCKR	
R	E1HT-9010129-AH		1	E1HZ-9010129-A		PNL ASY-BDY RCKR	
R	F1HT-9011140-AA		1	E8HZ-9011135-A		FLOOR PAN	
R	E3HT-9012110-DA		1	E3HZ-9012110-B		PLT FLR TRANS CVR	
R	D0HB-9012122-A		1			SEAL-FLR TRANS COV PLT	
R	D7HT-9024140-AAP3AI		1			ARM REST ASY DR TR RH	
R	D7HT-9024141-AAP3AI		1			ARM REST ASY DR TR LH	
R	F1HT-9027866-AB		1	F1HZ-9027866-A		PNL-BDY SD O/S FIN RR RH	
R	F1HT-9027867-AB		1	F1HZ-9027867-A		PNL-BDY SD O/S FIN RR LH	
R	E1HT-9050024-AAP6AW		1			CVR HD LINING ACCESS HOLE	
R	F0HT-9060004-BB00PG		1			ST.ASY.FRT.TR.PASS.RH.	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	FOHT-9060005-AB00PG		1			ST.ASY.FRT.TR.DRVR.LH.	
R	FOHT-9060094-ACJAA0		2			SUSP.ASY.DRVR.ST.	
R	E4TB-9860262-AAA5AE		2			CVR FRT ST SHLDR STRP GID	
U	1992014689001NVA00003		022H				HA840002199
R	D0EB-50044F58-A		1			COVER I/PNL CONT OPNG	
R	E6EB-58223A80-AA		2	F37Z-78223A80-A		DECAL-FRT DR WDO	
R	FOHT-60204A10-AA		1			DECAL ASY-SAF STD CERT	
R	C4AB-62618B58-A		1	C5AZ-6262060-A		RET-FRT ST TRK ADJ HANDLE	
R	F1HT-80016B78-AA		1	F1HZ-80016A22-A		REINF ASY - DASH PNL - R.	
R	F1HT-80016B79-AA		1	F1HZ-80016A23-A		REINF.ASY.DASH PNL.L.H.	
R	E7HT-80021A36-AA		1	E7HZ-80021A36-A		EXT ASSY-CWL TOP INR RH	
R	E7HT-80021A37-AA		1	E7HZ-80021A37-A		EXT ASSY-CWL TOP INR PNL	
R	EDE8HT-80022A53-AA		1	DOHZ-80022A45-A		EXT ASY CWL SD PNL LH	
R	E8HT-80025K90-AAP3A1		1	E8HZ-8003598-A		CVR ASSY-FRT BDY PLR RH	
R	E8HT-80025K91-AAP3A1		1	E8HZ-8003599-A		CVR ASSY-FRT BDY PLR LH	
R	E9HT-80044C40-FAP6DA		1	FOHZ-80044C40-B		PNL.-I.P.FINISH CNTR.	
R	E7HT-80044F14-AA		1	E7HZ-8004366-A		BRKT-I/PNL TO CWL SD EXT	
R	FOHT-80107A94-AB		1			MBR ASY-FLR PN CR RR	
R	D0HB-80111A22-B		1			EXT ASY FLR SD RR	
R	D0HB-80111A23-B		1			EXT ASY-FLR SD RR	
R	D0HB-80113B04-A		1			PLT FLR SD RR EXT RH	
R	D0HB-80113B05-A		1			PLT FLR SD RR EXT LH	
R	D0HB-80130B53-A		1			SUPT-FLR MAT	
R	E8HT-80211A00-AB		1	E8HZ-80211A00-A		FR-DR RH	
R	FOHT-80211A01-AA		1			FR-DR LH	
R	E9HT-80218A24-AA		2	F1HZ-8022152-A		ROD-DOOR LATCH ACTUATOR O	
R	D0HB-80219A59-A		2			SE-DR LAT R/CONTR RH	
R	E9HT-80220A28-AA		4	F1HZ-80220A28-A		RET - DR LAT ACTU	
R	D0HB-80222A34-A		2			BRKT DR VENT WDO DIV BAR	
R	D0HB-80223A24-A		1			RET & BRKT ASY DR VNT WDO	
R	D0HB-80223A25-A		1			RET & BRKT ASY DR VNT WDO	
R	E1HT-80237A04-AB		2	E1HZ-80237A04-A		SHLD-DR TR WTR	
R	FOHT-80278A24-BA		1			PNL-BDY RR CNR RH	
R	FOHT-80278A25-AA		1			PNL BDY RR CNR LH	
D	FOHS-80403A86-AA		1			MF FOHT-ABP3BP	92AE0000010
R	FOHT-80403B98-AA		1			REINF.ASY.-BK.PNL.EXH.MTN	
R	FOHT-80403B99-AA		1			REINF.ASY.BK.PNL.EXH.MTNG	
R	E4HT-80403D20-AA		1	DOHZ-80403D20-A		REINF ASY O/S ASST HNDL R	
R	E4HT-80403D21-AA		1	DOHZ-80403D21-A		REINF ASY O/S ASST HNDL L	
R	E8HT-80404A86-AB		1	DOHZ-90404A86-A		REINF-LWR BK TR PNL	
R	E8HT-80423A64-ABP3AY		1			RET-TRIM PNL	
R	E1HT-80500A00-AA		1	D5HZ-80500A00-A		FRM RF VENT	
R	FOHT-80513A16-AA		1			RAIL-RF SIDE OUTER REAR -	
R	FOHT-80513A17-AA		1			RAIL-RF SIDE OUTER REAR -	
R	E5HT-80513A30-AA		1	E5HZ-80513A30-A		RAIL RF SIDE INR RH	
R	E5HT-80513A31-BA		1	E5HZ-80513A31-B		RAIL RF SD	

VinNo	MY	GFile	OrdNo	Unit	Model	BuildDate	Customer
NVA00003	1992	022	014689	001	LTLA90	19901210	STOCK
R	FOHT-80602A04-AA		1			REINF ASY FRT ST SHLDR ST	
R	FOHT-80602A05-AA		1			REINF ASY FRT ST SHLDR ST	
R	FOHT-80611A72-CCJACH		1			BELT ASY.FRT.ST.COMPLETE	
R	FOHT-80611A73-CCJACH		1			BLT.RETR.ASY.FRT.ST.COMPT	
R	FOHT-80611C34-AC		1			BRKT ASY-FRT SEAT BELT RE	
R	FOHT-80611C35-AC		1			BRKT ASY-FRT SEAT BELT RE	
R	E1HT-80625A88-AA		2	E1HZ-80625A88-A		SUPT ASY-DRVR ST TO FLR	
R	C6UB-89268A76-A		2	C6UZ-89268A76-A		PIN-BDY SD DR HNG	
R	EDE9HT-90022A40-AA		1	E7HZ-90022A38-A		PNL ASSY-CWL SD FNSH OTR	
R	EDE9HT-90022A41-AA		1	E7HZ-90022A39-A		PNL ASSY-CWL SD FNSH OTR	
R	F1HT-90044F52-AA		1	E7HZ-9004551-A		REINF ASSY-I/PNL TO DSH	
R	E1HT-90104K38-AC		1	E1HZ-90104K38-A		BRKT ASSY-BDY RKR PNL RH	
R	E1HT-90104K39-AC		1	E1HZ-90104K39-A		BRKT ASSY-BDY RKR PNL LH	
R	F1HT-90113A52-AA		1	F1HZ-9012205-A		SEAL ASY-FLR PAN ACEL OPN	
R	F1HT-90113A52-BA		1	F1HZ-9012205-B		SEAL ASY-FLR PAN ACEL OPN	
R	F1HT-90279D26-AA		2	F1HZ-90279D26-A		BRKT ASSY-BDY SD O/S FIN	
R	F1HT-90280A60-CA		1			SHLD BDY SD LWR FRT(RH LW	
R	F1HT-90280A60-AA		1			SHLD BDY SD LWR FRT(RH FW	
R	F1HT-90280A60-BA		1			SHLD BDY SD LWR FRT(RH RR	
R	F1HT-90280A61-CA		1			SHLD BDY SD LWR FRT(LH LW	
R	F1HT-90280A61-AA		1			SHLD BDY SD LWR FRT(LH FW	
R	F1HT-90280A61-BA		1			SHLD BDY SD LWR FRT(LH RR	
R	F1HT-90281B32-BA		4	F1HZ-90281B32-A		RET BDY SD PNL UPR	
R	D7HT-90290C14-BA		2	D8HZ-9029024-B		HOOK-COAT	
R	F1HT-90291B22-AB		1			PNL-BDY SD O/S FIN FRT RH	
R	F1HT-90291B23-AB		1			PNL-BDY SD O/S FIN FRT LH	
R	F1HT-90291C60-VB		1			PNL-BDY SD O/S FIN CTR RH	
R	F1HT-90291C61-DB		1			PNL-BDY SD O/S FIN CTR LH	
R	E7HT-90403D30-BA		3	DOHZ-90403D30-A		RET BK TR PNL LWR	